

Neousys Technology Inc.

Nuvis-5306RT

User Manual

Rev. 1.0

Table of Contents

Table of Contents	2
Legal Information	7
Contact Information	8
Declaration of Conformity	8
Copyright Notice	9
Safety Precautions	10
Hot Surface Warning	10
Battery Warning	10
Service and Maintenance	11
ESD Precautions	11
Restricted Access Location	11
About This Manual	12

1 Introduction

1.1 Nuvis-5306RT Overview	13
1.2 Nuvis-5306RT-DTIO Specifications	14
1.3 Nuvis-5306RT-MCU Specifications	17
1.4 Isolated DIO Specifications	20
1.5 Supported CPUs	21
1.6 Dimension	22
1.6.1 Superior View	22
1.6.2 Front Panel View	23
1.6.3 Side View	23
1.6.4 Bottom View	24
1.7 Dimensions with Mount Bracket	25
1.7.1 Front View	25
1.7.2 Bottom View	25

2 System Overview

2.1 Nuvis-5306RT Packing List	26
2.2 Nuvis-5306RT Front Panel	27
2.2.1 DisplayPort	28
2.2.2 DVI Port	29
2.2.3 VGA Port	30
2.2.4 USB3.0 Port	31
2.2.5 Ethernet Port / PoE	32
2.2.6 On/ Off Ctrl & Status Output	33
2.2.7 System Status LED	34
2.2.8 Power Button	34
2.2.9 Reset Button	35
2.2.10 Cassette Enclosure	35
2.3 Nuvis-5306RT Rear Panel	36
2.3.1 SIM Card Slot	37
2.3.2 MCU Reset	37
2.3.3 Real-time Vision I/O	38
2.3.4 3.5mm Speaker-out/ Microphone-in Jack	38
2.3.5 COM Ports	39
2.3.6 USB2.0 Ports	40
2.3.7 3-Pin Terminal Block for DC and Ignition Input	41
2.4 Internal I/O Components	42
2.4.1 DDR4 SO-DIMM Slots	42
2.4.2 Dual Mode mSATA/ mini-PCIe Socket	43
2.4.3 mini-PCIe Socket	45
2.4.4 SATA Ports	47
2.4.5 Internal USB Port	48

3 System Installation

3.1	Disassembling the System Enclosure	50
3.2	CPU Installation Procedure	52
3.3	Memory Module Installation	55
3.4	Internal 2.5" SATA HDD/ SSD Installation	57
3.5	mini-PCIe Module Installation	60
3.6	PCIe Card Installation in Cassette Module	63
3.7	Installing the System Enclosure	66
3.8	DC Power Connection	68
3.9	Wall Mount/ Anti-Vibration Bracket Installation	69
3.9.1	Wall Mount Bracket Installation	69
3.10	Powering On the System	71
3.10.1	Powering On Using the Power Button	71
3.10.2	Powering On Using External Non-latched Switch	72
3.10.3	Powering On Using Wake-on-LAN	73

4 System Configuration

4.1	BIOS Settings	75
4.1.1	COM1 & COM3 Operating Mode	76
4.1.2	SATA Configuration	78
4.1.3	TPM Availability	80
4.1.4	CPU SKU Power Configuration	81
4.1.5	Wake on LAN Option	82
4.1.6	Power On after Power Failure Option	83
4.1.7	Boot Type (Legacy/ UEFI)	84
4.1.8	Boot Option for Newly Added Device	85
4.1.9	Watchdog Timer for Booting	86
4.1.10	Selecting Legacy/ UEFI Boot Device	88
4.2	AMT Configuration	89
4.3	RAID Volume Configuration	90

5 OS Support and Driver Installation

5.1	Operating System Compatibility	91
5.2	Install Drivers Automatically	92
5.3	Install Drivers Manually	93
5.3.1	For Windows 7 (x86)	93
5.3.2	For Windows 7 (x64)	93
5.3.3	For Windows 8 (x86)	93
5.3.4	For Windows 8 (x64)	94
5.3.5	For Windows 10 (x32)	94
5.3.6	For Windows 10 (x64)	94
5.4	Install WDT_DIO Driver Package	95
5.4.1	For Windows 7 (x86)	95
5.4.2	For Windows 7/ 8/ 10 (x64)	95
5.4.3	For Windows 7/ 8/ 10 (WOW64)	95

Appendix A: Windows 7 Installation

xHCI Driver Support in Microsoft OS	96
User Provided Items For Windows Installation	96
Creating Windows 7 Installation USB Flash Drive	97
Step 1 – Create .ISO File From Windows 7 DVD	97
Step 2 – Create USB Flash Drive Installer From .ISO	98
Step 3 – Create Folder and Copy Files For Patching Process	100
Step 4 – Execute .bat File to Patch .wim Files	101
Step 5 – Install Windows 7 Using USB Flash Drive Installer	103

Appendix B: Using WDT & DIO

WDT and DIO Library Installation	105
WDT Function Reference	107
InitWDT	107
SetWDT	107
StartWDT	108
ResetWDT	108
StopWDT	108
Using DIO Function.....	109
Wiring for DIO	109
DIO Pin Definition.....	110
DIO Function Reference	111
InitDIO	111
DIRReadLine	111
DIRReadPort	111
DOWriteLine.....	112
DOWritePort.....	112
DOWriteLineChecked	113
DOWritePortChecked.....	113
COS Function Reference.....	114
SetupDICOS	114
RegisterCallbackDICOS.....	115
StartDICOS	115
StopDICOS	116
DI COS Example.....	116

Appendix C: PoE On/ Off Control

GetStatusPoEPort.....	119
EnablePoEPort.....	120
DisablePoEPort.....	121

Appendix D: DTIOv2 Programming Guide

Programming Under Windows Environment.....	123
Step 1. WDT_DIO Library Installation	123
Step 2. Install Integrated Development Environment (IDE)	125
Step 3: Startup Visual Studio	125
Step 4: Execute 5306RTDemo.cpp file	126
Step 5: Build Solution.....	127
Step 6: Execute Local Windows Debugger	127
Step 7: Pre-configured Solution	128
Nuvis-5306RT Vision-Specific I/O: TB-10 Pin Assignment	129
Vision-Specific I/O Function Description	130

Programming with DTIOv2 Library

LED Brightness	132
Adjust the Brightness of LED	132
LED Function Reference	133
LED_SetCurrentDriving.....	133
LED Example -- Turn On and Off LED.....	134

Quadrature Encoder Interface (QEI)

The Concept of QEI.....	135
QEI Function Reference	136
QEI_Setup	136
QEI_Start	138
QEI_Stop	138
QEI_GetDirection	139
QEI_GetPosition	140
QEI_SetPosition.....	140

QEI Example 1-- Read Direction and Position	141
--	------------

Deterministic Trigger I/O version 2 (DTIOv2)

The Concept of DTIOv2	143
Trigger target.....	143
Trigger source	143
Channel.....	143
Four types of output signals	144
Trigger Mode	146
Time Unit.....	148
Delta.....	148
Time Unit and Delta.....	148
Total Time Unit (TTU)	148
Active Low.....	149
Trigger Target as Trigger Source.....	149
Software Trigger.....	150
DTIOv2 Function Reference	151
DT2_Setup.....	151
DT2_Start.....	155
DT2_Stop	156
DT2_SetUnit.....	156
DT2_GetUnit	157
DT2_StPush.....	157
DT2_StPull.....	158

DTIOv2 Programming Tips

DTIOv2 Example 1 - Infinite Pulse Train	162
DTIOv2 Example 2 - Use DI to Trigger LED.....	164
DTIOv2 Example 3 -- Software Trigger	166
DTIOv2 Example 4 - The Trigger Target as the Trigger Source	169

Appendix E: Advanced DTIOv2

The Concept of Advanced DTIOv2.....	172
Trigger Buffer	172
Trigger Buffer can be Applied to 8 Channels Simultaneously	174
External Input.....	174
Advanced DTIOv2 Function Reference	175
DT2_EiRegisterIndexed	175
DT2_EiSendResult.....	176
Advanced DTIOv2 Example 1 - Trigger Buffer.....	177
Advanced DTIOv2 Example 2 - External Input.....	180

Pulse Width Modulator (PWM)

The Concept of Pulse Width Modulator (PWM)	184
Configuring the Isolated Digital Output as PWM Output	184
PWM Function Reference.....	185
PWM_GenSetup	185
PWM_GenPeriod	186
PWM_PulseWidth	187
PWM_PulseInvert	187
PWM_Start.....	187
PWM_Stop.....	188
PWM Example.....	189

Advanced Examples

Combination PWM and DTIOv2.....	192
--	------------

Legal Information

All Neousys Technology Inc. products shall be subject to the latest Standard Warranty Policy

Neousys Technology Inc. may modify, update or upgrade the software, firmware or any accompanying user documentation without any prior notice. Neousys Technology Inc. will provide access to these new software, firmware or documentation releases from download sections of our website or through our service partners.

Before installing any software, applications or components provided by a third party, customer should ensure that they are compatible and interoperable with Neousys Technology Inc. product by checking in advance with Neousys Technology Inc.. Customer is solely responsible for ensuring the compatibility and interoperability of the third party's products. Customer is further solely responsible for ensuring its systems, software, and data are adequately backed up as a precaution against possible failures, alternation, or loss.

For questions in regards to hardware/ software compatibility, customers should contact Neousys Technology Inc. sales representative or technical support.

To the extent permitted by applicable laws, Neousys Technology Inc. shall NOT be responsible for any interoperability or compatibility issues that may arise when (1) products, software, or options not certified and supported; (2) configurations not certified and supported are used; (3) parts intended for one system is installed in another system of different make or model.

Contact Information

Headquarters (Taipei, Taiwan)	Neosys Technology Inc. 15F, No.868-3, Zhongzheng Rd., Zhonghe Dist., New Taipei City, 23586, Taiwan Tel: +886-2-2223-6182 Fax: +886-2-2223-6183 Email , Website
--	--

Americas (Illinois, USA)	Neosys Technology America Inc. 3384 Commercial Avenue, Northbrook, IL 60062, USA Tel: +1-847-656-3298 Email , Website
---	--

China	Neosys Technology (China) Ltd. Room 431, Building 32, Guiping Road 680, Shanghai 200233, China Tel: +86-2161155366 Email , Website
--------------	---

Declaration of Conformity

FCC	<p>This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at own expense.</p>
------------	--

CE	<p>The product(s) described in this manual complies with all applicable European Union (CE) directives if it has a CE marking. For computer systems to remain CE compliant, only CE-compliant parts may be used. Maintaining CE compliance also requires proper cable and cabling techniques.</p>
-----------	---

Copyright Notice

All rights reserved. This publication may not be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written consent of Neosys Technology, Inc.

Disclaimer

This manual is intended to be used as an informative guide only and is subject to change without prior notice. It does not represent commitment from Neosys Technology Inc. Neosys Technology Inc. shall not be liable for any direct, indirect, special, incidental, or consequential damages arising from the use of the product or documentation, nor for any infringement on third party rights.

Patents and Trademarks

Neosys, the Neosys logo, Expansion Cassette, MezIO™ are registered patents and trademarks of Neosys Technology, Inc.

Windows is a registered trademark of Microsoft Corporation.

Intel®, Core™ is a registered trademark of Intel Corporation

NVIDIA®, GeForce® is a registered trademark of NVIDIA Corporation

Texas Instruments (TI) and Sitara are registered trademarks of Texas Instruments Incorporated.

All other names, brands, products or services are trademarks or registered trademarks of their respective owners.

Safety Precautions

Read these instructions carefully before you install, operate, or transport the system.

- Install the system or DIN rail associated with, at a sturdy location
- Install the power socket outlet near the system where it is easily accessible
- Secure each system module(s) using its retaining screws
- Place power cords and other connection cables away from foot traffic. Do not place items over power cords and make sure they do not rest against data cables
- Shutdown, disconnect all cables from the system and ground yourself before touching internal modules
- Ensure that the correct power range is being used before powering the device
- Should a module fail, arrange for a replacement as soon as possible to minimize down-time
- By means of a power cord connected to a socket-outlet with earthing connection
- This product is intended to be supplied by a Listed Power Adapter or DC power source, rated 24Vdc, 16A, Tma 60 degree C and 5000m altitude during operation. If further assistance is required, please contact Neousys Technology
- If the system is not going to be used for a long time, disconnect it from mains (power socket) to avoid transient over-voltage

Hot Surface Warning



HOT SURFACE. DO NOT TOUCH. "ATTENTION: Surface chaude. Ne pas toucher."

WARNING!

Components/ parts inside the equipment may be hot to touch!
Please wait one-half hour after switching off before handling parts.

Battery Warning

Caution!



- Batteries are at risk of exploding if incorrectly installed
- Do not attempt to recharge, force open, or heat the battery
- Replace the battery only with the same or equivalent type recommended by the manufacturer

Service and Maintenance

- ONLY qualified personnel should service the system
- Shutdown the system, disconnect the power cord and all other connections before servicing the system
- When replacing/ installing additional components (expansion card, memory module, etc.), insert them as gently as possible while assuring connectors are properly engaged

ESD Precautions

- Handle add-on module, motherboard by their retention screws or the module's frame/ heat sink. Avoid touching the PCB circuit board or add-on module connector pins
- Use a grounded wrist strap and an anti-static work pad to discharge static electricity when installing or maintaining the system
- Avoid dust, debris, carpets, plastic, vinyl and styrofoam in your work area.
- Do not remove any module or component from its anti-static bag before installation

Restricted Access Location

The controller is intended for installation only in certain environments where both of the following conditions apply:

- Access can only be gained by QUALIFIED SERVICE PERSONNEL who have been instructed on the reasons for restrictions applied to the location and any precautions that shall be taken
- Access is through the use of a TOOL, lock and key, or other means of security, and is controlled by the authority responsible for the location

About This Manual

This manual introduces Neosys Technology Nuvis-5306RT, a fully featured machine vision controller that supports 6th generation Intel Core i7/ i5 processors with vision specific I/O, real-time control and GPU-computing.

Revision History

Version	Date	Description
1.0	Jul. 2020	Initial release

1 Introduction

Neosys' Nuvis-5306RT is a fully featured machine vision controller that supports 6th Gen Intel® Core™ i7/ i5 processors with vision specific I/Os, real-time control and GPU-computing.

1.1 Nuvis-5306RT Overview

Nuvis-5306RT features Intel® 6th Gen Core™ i7/i5 processor paired with Intel® Q170 Platform Controller Hub. It is the world's first fully featured machine vision controller in a compact footprint that integrates exceptional computing power, built-in camera interfaces and real-time vision-specific I/O controls.

Nuvis-5306RT provides a powerful machine vision platform with integrated LED lighting controller, camera trigger, encoder input, pulse width modulation (PWM) output and digital I/O, to simultaneously connect and control all vision devices. With Neosys' patented technologies, Deterministic Trigger I/O (DTIO) and NuMCU (based on MCU-based architecture), they manage all vision-specific I/Os and allow users to program a deterministic timing correlation between input and output signals in microsecond scale. In addition, the innovative NuMCU technology grants users full control of MCU by integrating programming environment, run-time download/debug capability, to achieve comprehensive I/O control.



Nuvis-5306RT features rich I/Os that include four IEEE 802.3at PoE, four USB 3.0, four USB 2.0, one VGA, two DisplayPorts, three serial COM, one mic-in and one speaker-out port. In addition, Nuvis-5306RT can also accommodate an NVIDIA® GeForce® GTX 950/ 1050 to leverage CPU-accelerated vision library or deep-learning vision applications. Combining built-in PoE+, USB 3.0 interfaces and the expandability for Camera Link and CoaXPress, Nuvis-5306RT is the ideal platform for demanding machine vision controller applications.

1.2 Nuvis-5306RT-DTIO Specifications

System Platform	
Processor	Supports 6 th -Gen Intel® Core™ LGA1151 CPU <ul style="list-style-type: none"> ● Intel® Core™ i7-6700 (8M Cache, 3.4/4.0 GHz, 65W TDP) ● Intel® Core™ i5-6500 (6M Cache, 3.2/3.6 GHz, 65W TDP) ● Intel® Core™ i7-6700TE (8M Cache, 2.4/3.4 GHz, 35W TDP) ● Intel® Core™ i5-6500TE (6M Cache, 2.3/3.3 GHz, 35W TDP)
Chipset	Intel® Q170 Platform
Graphics	Integrated Intel® HD Graphics 530
Memory	2x 260-pin SO-DIMM sockets, up to 32 GB DDR4 2133 MHz SDRAM
Vision Specific I/O Interface	
LED Lighting Controller	4-CH LED lighting controller output , supporting <ul style="list-style-type: none"> ● Constant current mode (up to 2A per channel, 100 kHz dimming control) ● Constant voltage mode (24 VDC, 100 kHz dimming control)
Camera Trigger	4-CH camera trigger output (12 VDC output)
Encoder Input	1-CH quadrature encoder input (A/B/Z)
Isolated Digital Output	4-CH isolated high-speed digital output (<2 us transient time, for strobe/PWM) 4-CH isolated high-current digital output (up to 500 mA rated current)
Isolated Digital Input	8-CH isolated high-speed digital input (<2 us transient time)
Real-time I/O Control	Patented MCU-based real-time I/O control with DTIO V2
I/O Interface	
Ethernet	1x Ethernet port by Intel® I219 5x Ethernet ports by Intel® I210
PoE+	4x IEEE 802.3at (80W total) Gigabit PoE+ (port 3 ~6)
Video Port	1x VGA supporting maximum 1920 x 1200 resolution 1x DVI-D supporting maximum 1920 x 1200 resolution 2x DisplayPort outputs, supporting maximum 4096 x 2304 resolution
USB	4x USB 3.0 ports (1000MB/s total bandwidth) via native xHCI controller 4x USB 2.0 ports
Serial Port	2x software-programmable RS-232/422/485 (COM1 & COM3) 1x RS-232 port (COM2)
Audio	1x mic-in and 1x speaker-out

Storage Interface	
SATA HDD	2x internal SATA port for 2.5" HDD/SSD (support RAID 0/ 1)
mSATA	1x full-size mSATA (mux with mini-PCIe)
Expansion Bus	
PCI/ PCI Express	1x PCIe x16 slot @ Gen3, 8-lanes PCIe signals in Cassette, supporting <ul style="list-style-type: none"> 75W NVIDIA® GPU COTS CameraLink and CoaXPress camera interface card
Mini PCI-E	1x internal mini PCI Express socket with front-accessible SIM socket 1x internal mini PCI Express socket with internal SIM socket (mux with mSATA)
Power Supply & Ignition Control	
DC Input	1x 3-pin pluggable terminal block for 8~35VDC DC input
Remote Ctrl. & Status Output	1x 10-pin (2x5) wafer connector for remote on/off control and status LED output
Max. Power Consumption	With Core™ i7-6700TE: 49.2W (2.05A@24V)* With Core™ i5-6500TE: 47.8W (1.99A@24V)* With Core™ i3-6100TE: 39.4W (1.64A@24V)*
Mechanical	
Dimension	240 mm (W) x 225 mm (D) x 111 mm (H)
Weight	4.5 kg (including CPU, GPU, memory and HDD)
Mounting	Wall mount bracket (standard) DIN-rail mounting (optional)
Environmental	
Operating Temperature	Using i7-6700TE or i5-6500TE , configured @ 35W TDP -25°C ~ 60°C ** Using i7-6700 or i5-6500 , configured @ 65W/ 51W TDP -25°C ~ 60°C */** (configured as 35W CPU mode) -25°C ~ 50°C */** (configured as 65W CPU mode)
Storage Temperature	-40°C ~85°C
Humidity	10%~90% , non-condensing
Vibration	Operating, 5 Grms, 5-500 Hz, 3 Axes (w/ SSD, according to IEC60068-2-64)
Shock	Operating, 50 Grms, Half-sine 11 ms Duration (w/ SSD, according to IEC60068-2-27)
EMC	CE/FCC Class A, according to EN 55032 & EN 55024

* For i7-6700 running at 65W mode, the high operating temperature shall be limited to 50°C and thermal throttling may occur when sustained full-loading applied. Users can

configure CPU power in BIOS to obtain higher operating temperature.

- **** *For sub-zero operating temperature, a wide temperature HDD drive or Solid State Disk (SSD) is required.*

**NOTE**

When running CPUs with greater than 35W TDP, the maximum operating temperature shall be limited to 50°C and thermal throttling may occur when sustained full-load is applied. Users can configure CPU power in BIOS to obtain higher operating temperature.

1.3 Nuvis-5306RT-MCU Specifications

System Platform	
Processor	Supports 6 th -Gen Intel® Core™ LGA1151 CPU <ul style="list-style-type: none"> ● Intel® Core™ i7-6700 (8M Cache, 3.4/4.0 GHz, 65W TDP) ● Intel® Core™ i5-6500 (6M Cache, 3.2/3.6 GHz, 65W TDP) ● Intel® Core™ i7-6700TE (8M Cache, 2.4/3.4 GHz, 35W TDP) ● Intel® Core™ i5-6500TE (6M Cache, 2.3/3.3 GHz, 35W TDP)
Chipset	Intel® Q170 Platform
Graphics	Integrated Intel® HD Graphics 530
Memory	2x 260-pin SO-DIMM sockets, up to 32 GB DDR4 2133 MHz SDRAM
Vision Specific I/O Interface	
LED Lighting Controller	4-CH LED lighting controller output , supporting <ul style="list-style-type: none"> ● Constant current mode (up to 2A per channel, 100 kHz dimming control) ● Constant voltage mode (24 VDC, 100 kHz dimming control)
Camera Trigger	4-CH camera trigger output (12 VDC output)
Encoder Input	1-CH quadrature encoder input (A/B/Z)
Isolated Digital Output	4-CH isolated high-speed digital output (<2 us transient time, for strobe/PWM) 4-CH isolated high-current digital output (up to 500 mA rated current)
Isolated Digital Input	8-CH isolated high-speed digital input (<2 us transient time)
Real-time I/O Control	NuMCU firmware
I/O Interface	
Ethernet	1x Ethernet port by Intel® I219 5x Ethernet ports by Intel® I210
PoE+	4x IEEE 802.3at (80W total) Gigabit PoE+ (port 3 ~6)
Video Port	1x VGA supporting maximum 1920 x 1200 resolution 1x DVI-D supporting maximum 1920 x 1200 resolution 2x DisplayPort outputs, supporting maximum 4096 x 2304 resolution
USB	4x USB 3.0 ports (1000MB/s total bandwidth) via native xHCI controller 4x USB 2.0 ports
Serial Port	2x software-programmable RS-232/422/485 (COM1 & COM3) 1x RS-232 port (COM2)
Audio	1x mic-in and 1x speaker-out

Storage Interface	
SATA HDD	2x internal SATA port for 2.5" HDD/SSD (support RAID 0/ 1)
mSATA	1x full-size mSATA (mux with mini-PCIe)
Expansion Bus	
PCI/ PCI Express	1x PCIe x16 slot @ Gen3, 8-lanes PCIe signals in Cassette, supporting <ul style="list-style-type: none"> 75W NVIDIA® GeForce® GPU COTS CameraLink and CoaXPress camera interface card
Mini PCI-E	1x internal mini PCI Express socket with front-accessible SIM socket 1x internal mini PCI Express socket with internal SIM socket (mux with mSATA)
Power Supply & Ignition Control	
DC Input	1x 3-pin pluggable terminal block for 8~35VDC DC input
Remote Ctrl. & Status Output	1x 10-pin (2x5) wafer connector for remote on/off control and status LED output
Max. Power Consumption	With Core™ i7-6700TE: 49.2W (2.05A@24V)* With Core™ i5-6500TE: 47.8W (1.99A@24V)* With Core™ i3-6100TE: 39.4W (1.64A@24V)*
Mechanical	
Dimension	240 mm (W) x 225 mm (D) x 111 mm (H)
Weight	4.5 kg (including CPU, GPU, memory and HDD)
Mounting	Wall mount bracket (standard) DIN-rail mounting (optional)
Environmental	
Operating Temperature	Using i7-6700TE or i5-6500TE , configured @ 35W TDP -25°C ~ 60°C ** Using i7-6700 or i5-6500 , configured @ 65W/ 51W TDP -25°C ~ 60°C */** (configured as 35W CPU mode) -25°C ~ 50°C */** (configured as 65W CPU mode)
Storage Temperature	-40°C ~85°C
Humidity	10%~90% , non-condensing
Vibration	Operating, 5 Grms, 5-500 Hz, 3 Axes (w/ SSD, according to IEC60068-2-64)
Shock	Operating, 50 Grms, Half-sine 11 ms Duration (w/ SSD, according to IEC60068-2-27)
EMC	CE/FCC Class A, according to EN 55032 & EN 55024

* For i7-6700 running at 65W mode, the high operating temperature shall be limited to 50°C and thermal throttling may occur when sustained full-loading applied. Users can configure CPU power in BIOS to obtain higher operating temperature.

** For sub-zero operating temperature, a wide temperature HDD drive or Solid State Disk

(SSD) is required.

**NOTE**

When running CPUs with greater than 35W TDP, the maximum operating temperature shall be limited to 50°C and thermal throttling may occur when sustained full-load is applied. Users can configure CPU power in BIOS to obtain higher operating temperature.

1.4 Isolated DIO Specifications

Isolated Digital Input	
No. of Channel	8-CH Isolated Digital Input Channels
Logic Level	Logic High: 5 to 24V Logic Low: 0 to 1.5V
Isolated Voltage	3750 Vrms
Transient time	< 2 μ s
Operation Mode	DTIOv2 \ NuMCU
Isolated Digital Output	
CH0~3 Isolated Digital Output Channels	
Operation Voltage	24V
Sink Current (per channel)	500 mA
Isolated Voltage	3750 Vrms
Operation Mode	DTIOv2 \ NuMCU
CH4~7 Isolated Digital Output Channels	
Sink Current (per channel)	350 mA
Transient time	< 2 μ s
Isolated Voltage	3750 Vrms
Operation Mode	DTIOv2 \ NuMCU
Camera Trigger	
Trigger Voltage	12V
Sink Current (per channel)	350 mA
Transient time	< 2 μ s
Isolated Voltage	3750 Vrms
Operation Mode	DTIOv2 \ NuMCU

1.5 Supported CPUs

The system supports Intel® 6th Gen. i7/ i5/ i3 processor via the LGA 1151 CPU socket.

- Intel® Core™ i7-6700 (8M Cache, 3.4/ 4.0 GHz, 65W TDP)
- Intel® Core™ i5-6500 (6M Cache, 3.2/ 3.6 GHz, 65W TDP)
- Intel® Core™ i7-6700TE (8M Cache, 2.4/ 3.4 GHz, 35W TDP)
- Intel® Core™ i5-6500TE (6M Cache, 2.3/ 3.3 GHz, 35W TDP)

Alternatively, you may also select a processor from Intel's embedded solution "[Products formerly Skylake](#)" that utilizes LGA1151 CPU socket.



NOTE


Other processors may result in different overall system power consumption or generate excess heat.

Avoid using CPUs not tested by Neosys Technology, as Neosys Technology may not be able guarantee the system's stability and functionality under its designated working environment.

If in doubt, please contact Neosys technical support!

1.6 Dimension

1.6.1 Superior View




NOTE

All measurements are in millimeters (mm).


1.6.2 Front Panel View

The numbers “2.5” represents the height of the rubber stands at 2.5mm.



1.6.3 Side View


The numbers “2.5” represents the height of the rubber stands at 2.5mm.



NOTE

All measurements are in millimeters (mm).

1.6.4 Bottom View




NOTE


All measurements are in millimeters (mm).

1.7 Dimensions with Mount Bracket

1.7.1 Front View



1.7.2 Bottom View



NOTE

All measurements are in millimeters (mm).


2 System Overview

Upon receiving and unpacking your system, please check immediately if the package contains all the items listed in the following table. If any item(s) are missing or damaged, please contact your local dealer or Neosys Technology.

2.1 Nuvis-5306RT Packing List


System Pack	Nuvis-5306RT	Qty
1	Nuvis-5306RT system (If you ordered graphics card/ CPU/ RAM/ HDD, please verify these items)	1
2	Accessory box, which contains CPU bracket Neosys Drivers & Utilities DVD Wall-mounting bracket Foot pad 3-pin pluggable terminal block HDD thermal pad for 2.5" HDD/SSD (if HDD is not installed) Screw pack PORON® form strip, 91 x 12 x 10 mm Rubber spacer (available for barebone only) Fan 40x40x10 mm TB-10 SCSI-68 Male to SCSI-68 Male 100cm cable	1 1 2 4 1 1 1 4 4 1 1 1

2.2 Nuvis-5306RT Front Panel



No.	Item	Description
1	DisplayPort 1 & 2	Support display resolutions up to 4096 x 2304. Compatible with HDMI/ DVI via respective adapter/ cable (support resolution may vary).
2	DVI port	DVI-D output supports resolution up to 1920x1200@60Hz and is compatible with other digital connections via an adapter
3	VGA port	VGA output supports resolution up to 1920x1200@60Hz
4	USB 3.0 ports	USB 3.0 port, up to 5Gbit/s data transfer bandwidth.
5	GbE ports	Gigabit Ethernet ports offer fast network access.
6	On/ off control & status output	Allows for external switch extension when the system is placed inside a cabinet.
7	PoE+ GbE ports	Power over Ethernet (PoE) port can provide both data connection and electric power to devices (eg. IP camera).
8	System status LEDs	Four system LEDs, Ignition control (IGN), Watchdog Timer (WDT), Hard Disk Drive (HDD) and Power (PWR).
9	Power button	Use this button to turn on or force shutdown the system.
10	Reset button	Use this button to manual restart the system.
Area in Green	Cassette Enclosure	The cassette enclosure offers a separate compartment to manage thermal conditions and reduce installation complications of an add-on card.

2.2.1 DisplayPort



The system has dual DisplayPort (DP) outputs which are digital display interfaces that mainly connect video source and carry audio to a display device. When connecting a single DP, it can deliver up to 4096 x 2304 resolution and each port can deliver up to 2880 x 1800 resolution when both DPs are connected in conjunction. The system is designed to support passive DP adapter/ cable. You can connect to display devices using DP-to-HDMI cable or DP-to-DVI cable.



DP-to-HDMI




DP-to-DVI

The system supports triple independent display outputs in the following combination of VGA, DVI and DisplayPort. To support multiple display outputs and achieve best DVI output resolution in Windows, you need to install corresponding graphics driver. Please refer to section [OS Support and Driver Installation](#) for details.

Triple Independent Display Configuration (resolution may be limited)

Active display 1	Active display 2	Active display 3
DisplayPort	DisplayPort	DVI or VGA
DisplayPort	DVI	VGA

2.2.2 DVI Port




DVI-D transmits graphics data in digital format and therefore can deliver better image quality at high resolution. The DVI connector on the front panel can either output DVI signals or other digital signals (via an adapter/ cable) depending on the display device connected. It supports resolutions up to 1920x1200@60Hz.

The system supports triple independent display outputs in the following combination of VGA, DVI and DisplayPort. To support multiple display outputs and achieve best DVI output resolution in Windows, you need to install corresponding graphics driver. Please refer to section [OS Support and Driver Installation](#) for details.

Triple Independent Display Configuration (resolution may be limited)

Active display 1	Active display 2	Active display 3
DisplayPort	DisplayPort	DVI or VGA
DisplayPort	DVI	VGA

2.2.3 VGA Port



VGA connector is the most common video display connection. The VGA output supports up to 1920x1200@60Hz resolution. By default, the VGA output is set to “always-on”. For users who want to use only digital display interface (eg. DVI or DP), the VGA Output setting can be disabled. To disable, press F2 upon system startup, go to “**Advanced > System Agent (SA) Configuration > Graphics Configuration > VGA Output > [Disable]**”.

The system supports triple independent display outputs in the following combination of VGA, DVI/ HDMI and DisplayPort. To support multiple display outputs and achieve best DVI output resolution in Windows, you need to install corresponding graphics driver. Please refer to section [OS Support and Driver Installation](#) for details.

Triple Independent Display Configuration (resolution may be limited)


Active display 1	Active display 2	Active display 3
DisplayPort	DisplayPort	DVI or VGA
DisplayPort	DVI	VGA



NOTE

Please make sure your VGA cable includes SDA and SCL (DDC clock and data) signals for correct communication with monitor to get resolution/timing information. A cable without SDA/ SCL can cause blank screen on your VGA monitor due to incorrect resolution/timing output.


2.2.4 USB3.0 Port



The system offers four USB 3.0 (SuperSpeed USB) ports on its front panel. They are implemented via native xHCI (eXtensible Host Controller Interface) controller in Q170 chipset and are backward compatible with USB 2.0, USB 1.1 and USB 1.0 devices. Legacy USB support is also provided so you can use USB keyboard/mouse in DOS environment.

Due to the nature that XHCI driver is not included natively in Windows 7, you may encounter the issue of USB keyboard/mouse not working when installing Windows 7. Neousys offers a Windows-based batch file and step-by-step guide to help you. Please refer to [Appendix A Windows 7 Installation](#) for information on installing Windows 7.

2.2.5 Ethernet Port / PoE



The system offer two GbE ports (in **red** and **blue**) and four additional PoE (Power over Ethernet) ports marked in **green**. The port marked in **blue** is implemented using Intel® I219-LM that supports Wake-on-LAN and is also compatible with [Intel® AMT \(Active Management Technology\)](#) to support advanced features such as remote SOL desktop and on/off.

Power over Ethernet (PoE) supplies electrical power and data on a standard CAT-5/CAT-6 Ethernet cable. Acting as a PoE PSE (Power Sourcing Equipment), compliant with IEEE 802.3at, each PoE port delivers up to 25W (Max. 80W total) to a Powered Device (PD). PoE can automatically detect and determine if the connected device requires power or not, so it is compatible with traditional Ethernet devices as well.

Each port has one dedicated PCI Express link for maximum network performance. Please refer to the table below for LED connection statuses.

Active/Link LED (Right)


LED Color	Status	Description
Yellow	Off	Ethernet port is disconnected
	On	Ethernet port is connected and no data transmission
	Flashing	Ethernet port is connected and data is transmitting/receiving

Speed LED (Left)


LED Color	Status	Description
Green or Orange	Off	10 Mbps
	Green	100 Mbps
	Orange	1000 Mbps

To utilize the GbE port in Windows, you need to install corresponding driver for Intel® I210-IT/ I219-LM GbE controller.

2.2.6 On/ Off Ctrl & Status Output



The “On/ Off Control Ctrl & Status Output” connection allows for external switch and LED indicator extension. It is useful when the system is placed in a cabinet or a not easily accessed location. This function is provided via a 2x5 2.0mm pitch wafer connector.



Pin#	Definition	Description
1	Ctrl+	[Input] Remote on/off control, connecting to an external switch to turn on/off the system (polarity is negligible).
2	Ctrl-	
3	Power+	[Output] System power indicator, on if system is turned on, off if system is turned off.
4	Power-	
5	HDD+	[Output] Hard drive indicator, flashing when SATA hard drive is active.
6	HDD-	
7	Standby Power+	[Output] Standby power indicator, lighting up when DC power is applied and system is in S5 (standby) mode.
8	Standby Power-	
9	WDT+	[Output] Watchdog timer indicator, flashing when watchdog timer is started.
10	WDT-	




NOTE

Please make sure the polarity is correct when you connect the external LED indicator to the Status LED Output. The status LED output has a built-in series resistor and provides 3.3V, 10mA current, which means you can use these pins o directly drive an

external LED indicator.


2.2.7 System Status LED



There are four LED indicators on the front panel: PWR, HDD, WDT and IGN. The descriptions of these four LEDs are listed in the following table.

Indicator	Color	Description
IGN	NA	NA
WDT	Yellow	Watchdog timer indicator, flashing when WDT is active
HDD	Red	Hard drive indicator, flashing when SATA drive is active
PWR	Green	Power indicator, light when system is on


2.2.8 Power Button



The power button is a non-latched switch for ATX mode on/off operation. To turn on the system, press the power button and the PWR LED should light-up green. To turn off the system, issuing a shutdown command in OS is preferred, or you can simply press the power button. To force shutdown when the system freezes, press and hold the power button for 5 seconds. Please note that there is a 5-second interval


between on/off operations (i.e. once turning off the system, there is a 5-second wait before you can power-on the system).

2.2.9 Reset Button



The reset button is used to manually reset the system in case of system halt or malfunction. To avoid unexpected resets, the button is purposely placed behind the panel. To reset, please use a pin-like object (eg. tip of a pen) to access the reset button.


2.2.10 Cassette Enclosure



Neousys' patented expansion Cassette (R.O.C. Patent No. M456527) is an innovation design for fanless controller. It provides a separated compartment to accommodate an add-on card. It effectively manages thermal conditions of both the system and the add-on card. The modular concept brought by Cassette also reduces the complexity of installing and replacing an add-on card in the fanless controller. The Cassette enclosure itself incorporates an innovative mechanical design to effectively deal with the heat generated by GPU. This patented architecture (R.O.C. Patent No. M534371) creates a sealed wind tunnel to bring in cold air to the GPU


and expels hot air via a system fan. The design offers the system extreme stability and reliability when operating at 60°C with the GPU under 100% load. The expansion Cassette enclosure accepts dual-slot graphics cards with up to 75W TDP.

2.3 Nuvis-5306RT Rear Panel




No.	Item	Description
1	SIM card slot	With a 3G/ 4G module installed, insert a SIM card to access the operator's network.
2	MCU reset button	Press the button to reset the MCU.
3	Real-time Vision I/O	Vision specific trigger/ strobe control input/ output for vision/ imagery purposes.
4	Microphone-in jack	Microphone-in jack for voice (microphone) input.
5	Speaker-out jack	Speaker-out jack for sound output.
6	COM ports	There are 3 COM ports for communicating with external devices.
7	USB 2.0	The USB 2.0 ports are compatible with USB 1.1 / 1.0.
8	3-pin terminal block (DC/ ignition input)	Compatible with DC power input from 8~35V, the terminal block is also used for ignition signal input.
9	Area in green	The panel opening of the cassette enclosure. When an expansion card is installed, connectors are accessible on this panel.

2.3.1 SIM Card Slot




On the rear panel, there is a panel-accessible SIM socket. By installing a 3G/4G module onto the internal mini-PCIe port, you can have Internet access via telecom operator's network. The SIM socket is a push-push type. The push-push mechanism means the SIM card is push-to-install and push-to-retrieve. Please note that the SIM card must be inserted upside down (gold fingers facing upward).

2.3.2 MCU Reset




You may use the MCU reset button to manually reset the MCU without resetting the whole system. To avoid unexpected resets, the button is purposely placed behind the panel. To reset, please use a pin-like object (eg. tip of a pen) to access the reset button.



2.3.3 Real-time Vision I/O




Real-time vision I/O is managed by Neosys' patented MCU-based architecture and DTIO/ NuMCU firmware for microsecond-scale real-time I/O control. It also supports various machine vision peripherals such as CC/ CV lighting controller, quadrature encoder input, PWM output, isolated DI/ DO, 12V camera trigger output etc.

2.3.4 3.5mm Speaker-out/ Microphone-in Jack




The audio function on Nuvis-5306RT uses Intel® High Definition Audio in Q170 chipset and Realtek ALC262 codec. There are two audio function jacks, the  port is used for microphone input, and the  port is used for speaker / headphone output. To utilize the audio function in Windows, you need to install corresponding drivers for both Intel® Q170 chipset and Realtek ALC262 codec.

2.3.5 COM Ports




The system has three COM ports for communicating with external devices. COM1, COM2 and COM3 ports are located on the rear panel via 9-pin D-Sub male connectors. They are implemented using industrial-grade ITE8786 Super IO chip (-40 to 85°C) and provide up to 115200 bps baud rate.

COM1 and COM3 are software-configurable RS-232/422/485 ports and COM2 is a standard 9-wire RS-232 port. The operation mode, slew rate and termination of COM1 and COM3 can be set in BIOS setup utility. The following table describes the pin definition of COM ports.



Pin#	COM1 / COM3			COM2
	RS-232 Mode	RS-422 Mode	RS-485 Mode (Two-wire 485)	RS-232 Mode
1	DCD	-	-	DCD
2	RX	422 TXD+	485 TXD+/RXD+	RX
3	TX	422 RXD+	-	TX
4	DTR	422 RXD-	-	DTR
5	GND	GND	GND	GND
6	DSR	-	-	DSR
7	RTS	-	-	RTS
8	CTS	422 TXD-	485 TXD-/RXD-	CTS
9	RI	-	-	RI


2.3.6 USB2.0 Ports



The USB2.0 ports are implemented via native xHCI (eXtensible Host Controller Interface) controller in Q170 chipset and are backward compatible with USB 1.1 and USB 1.0 devices. Legacy USB support is also provided so you can use USB keyboard/mouse in DOS environment.

Due to the nature that XHCI driver is not included natively in Windows 7, you may encounter USB keyboard/ mouse not working when installing Windows 7. Neosys offers a Windows-based batch file and step-by-step guide to help you. Please refer to [Appendix A Windows 7 Installation](#) for information on installing Windows 7.

2.3.7 3-Pin Terminal Block for DC and Ignition Input



The system allows an 8 to 35V DC power input from via a 3-pin pluggable terminal block. The screw clamping mechanism is a reliable way to wire DC power. The ignition signal input (IGN) is not applicable to the system.




WARNING

Please make sure the voltage of DC power is correct before you connect it to the system. Supplying a voltage over 35V will damage the system.

2.4 Internal I/O Components


The internal components of Nuvis-5306RT series include two SODIMM sockets, SATA ports, mSATA, mini-PCIe sockets and an internal USB port.

2.4.1 DDR4 SO-DIMM Slots



The system provides two 260-pin DDR4 memory SO-DIMM sockets. It can support up to 32GB maximum capacity by installing two 16GB DDR4 2133 MHz SODIMM modules.


2.4.2 Dual Mode mSATA/ mini-PCle Socket



The system provides a dual mode mSATA/ mini-PCle socket that is in compliance with mini-PCle specification rev. 1.2. You can install either an mSATA SSD or mini-PCle module into this socket and the system will automatically detect and configure it to run PCIe or SATA signals. This mini-PCle socket is designed with SIM card support. With a SIM card installed, your system can access the internet via your network provider's 3G/ 4G network.

For wireless (WIFI/ 3G/ 4G) communication, multiple SMA antenna apertures can be located on the front and rear panel.

Dual mode mSATA/ mini-PCle socket definition




Pin	Signal (mPCle)	Signal (mSATA)	Pin #	Signal (mPCle)	Signal (mSATA)
1	WAKE#	-	2	+3.3Vaux	+3.3Vaux
3	COEX1	-	4	GND	GND
5	COEX2	-	6	+1.5V	+1.5V
7	CLKREQ#	-	8	UIM PWR	-
9	GND	GND	10	UIM DATA	-
11	REFCLK-	-	12	UIM CLK	-
13	REFCLK+	-	14	UIM RESET	-
15	GND	GND	16	UIM VPP	-
Mechanical Key					
17	Reserved*	-	18	GND	GND
19	Reserved*	-	20	W_DISABLE#	-
21	GND	GND	22	PERST#	-
23	PERn0	SATA Rxp	24	+3.3Vaux	+3.3Vaux
25	PERp0	SATA Rxn	26	GND	GND
27	GND	GND	28	+1.5V	+1.5V
29	GND	GND	30	SMB CLK	SMB CLK
31	PETn0	SATA Txn	32	SMB DATA	SMB DATA
33	PETp0	SATA Txp	34	GND	GND
35	GND	GND	36	USB D-	-
37	GND	GND	38	USB D+	-
39	+3.3Vaux	+3.3Vaux	40	GND	GND
41	+3.3Vaux	+3.3Vaux	42	LED WWAN#	-
43	GND	-	44	LED WLAN#	-
45	Reserved	-	46	LED WPAN#	-
47	Reserved	-	48	+1.5V	+1.5V
49	Reserved	-	50	GND	GND
51	Reserved	-	52	+3.3Vaux	+3.3Vaux



WARNING


Some off-the-shelf mini-PCle 4G modules are not compliant to standard mini-PCle interface. They use 1.8V I/O signals instead of standard 3.3V I/O and may have signal conflict. Please consult with Neousys for compatibility when in doubt!
Installing an incompatible 4G module may damage the system or the module itself may be damaged.

2.4.3 mini-PCle Socket



This mini-PCle socket works in cooperation with the panel-accessible SIM slot. By installing a mini-PCle module, you can add additional features to your system such as WIFI, GPS, CAN bus, analog frame grabber, etc. You can also install a 3G/4G module and SIM card for internet via your service provider's 3G/ 4G network.

For wireless (WIFI/ 3G/ 4G) communication, multiple SMA antenna apertures can be located on the front and rear panel.

mini-PCle Pin Definition



Pin #	Signal	Pin #	Signal
1	WAKE#	2	+3.3Vaux
3	COEX1	4	GND
5	COEX2	6	+1.5V
7	CLKREQ#	8	UIM PWR
9	GND	10	UIM DATA
11	REFCLK-	12	UIM CLK
13	REFCLK+	14	UIM RESET
15	GND	16	UIM VPP
Mechanical Key			
17	Reserved* (UIM C8)	18	GND
19	Reserved* (UIM C4)	20	W DISABLE#
21	GND	22	PERST#
23	PERn0	24	+3.3Vaux
25	PERp0	26	GND
27	GND	28	+1.5V
29	GND	30	SMB CLK
31	PETn0	32	SMB DATA
33	PETp0	34	GND
35	GND	36	USB D-
37	GND	38	USB D+
39	+3.3Vaux	40	GND
41	+3.3Vaux	42	LED WWAN#
43	GND	44	LED WLAN#
45	Reserved	46	LED WPAN#
47	Reserved	48	+1.5V
49	Reserved	50	GND
51	Reserved	52	+3.3Vaux


WARNING

Some off-the-shelf mini-PCle 4G modules are not compliant to standard mini-PCle interface. They use 1.8V I/O signals instead of standard 3.3V I/O and may have signal conflict. Please consult with Neousys for compatibility when in doubt!

Installing an incompatible 4G module may damage the system or the module itself may be damaged.


2.4.4 SATA Ports



The system provides two SATA ports which support Gen3, 6 Gb/s SATA signals. Each SATA port (indicated in **red**) features a 7-pin SATA connector and a 4-pin power connector.

The power plug (indicated in **blue**) accommodates a 2.5" HDD/ SSD in internal HDD bracket. Standard 22-pin SATA connectors are provided with the system. You may refer to the [SATA Configuration](#) section for SATA settings.

2.4.5 Internal USB Port



The system has an internal USB2.0 port on the PCBA. You can utilize this USB port to connect a USB protection dongle inside the chassis of the system.

3 System Installation

Before disassembling the system enclosure and installing components and modules, please make sure you have done the following:

- It is recommended that only qualified service personnel should install and service this product to avoid injury or damage to the system.
- Please observe all ESD procedures at all times to avoid damaging the equipment.
- Before disassembling your system, please make sure the system has powered off, all cables and antennae (power, video, data, etc.) are disconnected.
- Place the system on a flat and sturdy surface (remove from mounts or out of server cabinets) before proceeding with the installation/ replacement procedure.

3.1 Disassembling the System Enclosure

1. Turn the system upside-down.
2. Unscrew the four (4) screws indicated at the bottom of the Cassette enclosure.



3. Gently lift and separate the Cassette enclosure from the system enclosure.




4. Remove the seven screws on the front panel shown in the illustration below.



5. Remove the seven screws on the rear panel shown in the illustration below.




6. Gently lift the base panel and remove front and rear panels



3.2 CPU Installation Procedure

1. DO NOT remove the CPU from its container / tray before it is ready to be installed.
2. Once the enclosure panels have been removed and to install a CPU into the system, remove the four (4) M3 P-head screws in the illustration below.



3. Gently lift the motherboard off the heatsink and turn the motherboard upside-down. You'll see the CPU socket protective cover, place finger tips under the sign "REMOVE" for leverage. Gently lift the cover.




WARNING

With the protective cover removed, please be careful when handling the motherboard. DO NOT touch the pins in the LGA socket!

4. Remove the CPU from its container/ tray. Match the two notches on the side to the protrusions in the socket, gently lower the CPU into the socket.




5. Locate the CPU retention bracket in the accessory box. Place the retention bracket on the CPU and hold it in place, turn the motherboard around and secure the bracket by tightening two (2) M3 P-head screws.



**Retention bracket screw
location**




**Secure two M3 P-head screws on the
opposite side**




Hold bracket/ CPU in place along with the motherboard


6. Remove all thermal pad protective films pre-placed on the heatsink.



7. With the four (4) motherboard standoffs aligned (please refer to step 2), gently lower the motherboard onto the heatsink
8. Secure the four (4) M3 P-head motherboard screws (indicated in **yellow**) and from the accessory box, five (5) M3 spring screws (indicated in **red**). Gradually tighten the five screws in the following order for even pressure.



Securing the motherboard




Secure five CPU/ heatsink spring screws in order

9. Reinstall the system enclosure and panel when done.
10. If you need to install other components, please refer to respective sections.

3.3 Memory Module Installation

There are two memory SO-DIMM slots on the motherboard that support a total maximum of 32GB DDR4-2133. Please follow the procedures below to replace or install the memory modules.

1. To disassemble the enclosure, please refer to the section "[Disassembling the System Enclosure](#)".
2. The SO-DIMM slots can be located once the bottom cover of the enclosure has been removed.



3. To install the memory module, insert gold fingers of the module into the slot at 45 degree angle.



4. Push down on the edge of the module and the clips on the side should clip the module into place.



5. Repeat steps above to install the other module.
6. Reinstall the system enclosure and panel when done.
7. If you need to install other components, please refer to respective sections.

3.4 Internal 2.5" SATA HDD/ SSD Installation

The system has two SATA ports for connecting SATA HDD/ SSD, one internal and one external. Please follow the procedures below to install or replace the hard drives.

1. Place the system upside down on a flat surface and loosen the three (3) screws show below.



2. Remove the protective films on the thermal pad situated in the center of the bracket.



3. Place the HDD/ SSD on the bracket, gently press it down against the thermal pad. From the accessory box, use M3 flat-head screws to secure the HDD/ SSD. Make sure the HDD/ SSD is secured in the same orientation as shown in the illustration below.



4. Connect the SATA cable inside the enclosure to the HDD/ SSD




5. Gently wiggle the bracket back into the enclosure and secure it with three (3) M3 flat-head screws.




3.5 mini-PCle Module Installation

Please refer to the following procedures on how to install a mini-PCle module.

1. To disassemble the enclosure, please refer to the section "[Disassembling the System Enclosure](#)".
2. Remove the MezIO module by unfastening the three (3) screws shown below.



3. Location of the mini-PCIe sockets on the motherboard shown below. The SIM slot of mini-PCIe socket (in **red**) is situated on the rear panel.



4. Inset the mini-PCIe module's gold finger on a 45 degree angle into the socket, gently press the module down and secure it with an M2.5 P-head screw.




45 degree insertion angle




Secured with M2.5 P-head screw

5. Clip on the IPEX-to-SMA cable to the module and attach the antenna onto the front or rear panel.




Clip on IPEX-to-SMA cable



Attach antenna to panel

6. Insert the SIM card (if necessary) for your mini-PCle module.




7. The mini-PCle socket (in **red**) works in conjunction with the panel-accessible SIM slot on the rear panel, while other mini-PCle sockets work with internal SIM slots. Insert the SIM upside down for 3G/ 4G access via your provider's network. Push the SIM card into the panel, make sure it clicks into the slot and is seated firmly (not protruding) in the slot.
8. Reinstall the system enclosure and panel when done.
9. If you need to install other components, please refer to respective sections.

3.6 PCIe Card Installation in Cassette Module

For demonstration, we will be using a NVIDIA Geforce GTX 1050Ti as an example.


1. Unfasten the three M3 flat-head screws at the bottom of the Cassette module (please refer to [Disassembling the System Enclosure](#) on Cassette module removal) and remove Cassette module's bottom panel.




2. Remove the PCIe slot cover and gently lower the PCIe graphics card by matching the PCIe gold fingers into the slot.




3. Make sure the bottom of the graphics card slot cover is properly inserted into the hinge on the enclosure.



4. Secure the graphics card's slot cover with two (2) M3 flat-head screws.



5. Reinstall the Cassette enclosure and secure it with the three (3) M3 flat-head screws shown below.



3.7 Installing the System Enclosure

1. To reinstall the system enclosure, fit the front and rear panels and gently lower the base panel.



2. Secure the seven (7) screws on the front panel.



3. Secure the seven (7) screws on the rear panel.



4. Gently lower the Cassette module while matching the four position poles.




5. Secure the Cassette module by securing the four (4) screws.



3.8 DC Power Connection

The system uses a 3-pin pluggable terminal block to accept 8~35V DC power input. It is a reliable, convenient and easy method to directly wire cables to the DC power connector. The pluggable terminal block is also used to accept ignition signal To connect DC power via the 3-pin pluggable terminal block, please refer to the procedures described below.



1. Before connecting the cables, please make sure the DC power supply is unplugged!
2. Take the 3-pin pluggable terminal block out of the accessory box. The terminal block fits the wires with a gauge of 12~24 AWG.
3. Carefully identify the positive and negative contacts of your DC power supply and the pluggable terminal block. The polarities between DC power supply and terminal block must be positive (+) to positive (+) and ground (GND) to ground (GND).
4. Insert the wires to the matching pluggable terminal block contacts and tighten clamping screws using a Philips screwdriver.
5. Plug in the terminal plug into the 3-pin pluggable terminal block on the system enclosure and secure the plug using a flat-head screwdriver.



WARNING

The system accepts 8~35 VDC when using terminal block for DC input. Please make sure the voltage and polarity of DC power is correct before you connect and power on the system. Supplying a voltage over 35V or incorrect polarity will damage the system!

3.9 Wall Mount/ Anti-Vibration Bracket Installation

Nuvis-5306RT features a patented mechanical design that creates a sealed tunnel for air flow. To obtain best efficiency for heat dissipation, it is recommended that a minimum clearance of 20mm is reserved at the bottom side of Nuvis-5306RT controller. Nuvis-5306RT is shipped with stand-off brackets designed to create a 20mm clearance. To mount your Nuviso-5306RT controller on the wall or flat surface, please refer to the instructions listed below.




NOTE


1. You will need to remove the four (4) rubber stands at the bottom of the enclosure if they have been attached.
2. For customers using customized mounting design, please make sure you have at least 20mm clearance underneath the system. Mounting the system without the recommended minimum clearance may significantly reduce GPU performance at high ambient temperature.

3.9.1 Wall Mount Bracket Installation


1. Get two wall-mounting brackets and four M4 screws from the accessory box. Fix the mounting brackets onto the bottom of the system using M4 screws.



2. Place the system on a flat surface and fix it with screws. You can also take advantage of the keyhole-shaped holes on mounting brackets to suspend the system on the Wall.



3. When wall mounting, please mount the system's in the direction so the heatsink's fins are placed vertically for optimal heat dissipation efficiency.




3.10 Powering On the System

There are three methods to power on the system

- [Pressing the power button](#)
- [Via an external non-latched switch](#)
- [Sending a LAN packet via Ethernet \(Wake-on-LAN\)](#)

3.10.1 Powering On Using the Power Button

This is the simplest way to turn on your system. The power button on the front panel is a non-latched switch and behaves as the ATX-mode on/off control. With DC power connected, pushing the power button will turn on the system and the PWR LED indicator will light up. Pushing the button when system is on will turn off the system. If your operating system supports ATX power mode (i.e. Microsoft Windows or Linux), pushing the power button while the system is in operation will result in a pre-defined system behavior, such as shutdown or hibernation.




3.10.2 Powering On Using External Non-latched Switch

If your application demands the system to be placed inside a cabinet, you may use an external non-latched switch to power on/ off the system. The system provides a [“On/ Off Control Ctrl & Status Output”](#) connection (a 2x5, 2.0mm pitch wafer connector) for connecting a non-latched switch and acts as the ATX-mode power on/off control switch. The external non-latched switch acts exactly the same as the power button on the front panel. To setup and power on/ off the system using an external non-latched switch (ATX-mode), please follow the steps described below.


1. Acquire a non-latched switch with a 2x5, 2.0mm pitch wafer terminal and the switch must be connected to pin#1 and pin #2 (polarity is negligible).



2. Connect the wafer terminal to the “On/Off Control Ctrl & Status Output” connector on the system



On/Off Control Ctrl & Status Output




Pin #1 and Pin #2

3. With DC power connected, pushing the power button will turn on the system and the PWR LED indicator will light up. Pushing the button when system is on will turn off the system. If your operating system supports ATX power mode (i.e. Microsoft Windows or Linux), pushing the power button while the system is in operation will result in a pre-defined system behavior, such as shutdown or hibernation.

3.10.3 Powering On Using Wake-on-LAN

Wake-on-LAN (WOL) is a mechanism to wake up a computer system from a S5 (system off with standby power) state via issuing a magic packet. The system's Wake-on-LAN compatible GbE port is shown below.




NOTE


Please make sure the Intel chipset and Ethernet driver has been properly installed prior to setting up WOL function.

To enable WOL function, please set up WOL settings in the BIOS and in the operating system by follow the steps described below.

1. When the system boots up, press F2 to enter BIOS setup utility.
2. Go to the **[Power] > [Wake On LAN]** and set it to **[Enabled]**.
3. Press F10 to **"Save changes and exit BIOS"** and allow the system boot into the operating system.
4. Once booted into the Windows system, press **"Windows key + E"**, right-click on **"Network > Properties > Change adapter settings"**. Locate and double-click on the adapter Intel® I219 Gigabit Network Connection, click on **Configure...**



5. Click on the **Power Management** tab and check the following options. Click on OK when done.



Magic Packet

The magic packet is a broadcast frame containing anywhere within its payload 6 bytes of all 255 (FF FF FF FF FF FF in hexadecimal), followed by sixteen repetitions of the target computer's 48-bit MAC address.

For example, NIC's 48-bit MAC Address is 78h D0h 04h 0Ah 0Bh 0Ch

DESTINATION SOURCE MISC

FF FF FF FF FF FF

78 D0 04 0A 0B 0C	78 D0 04 0A 0B 0C
78 D0 04 0A 0B 0C	78 D0 04 0A 0B 0C
78 D0 04 0A 0B 0C	78 D0 04 0A 0B 0C
78 D0 04 0A 0B 0C	78 D0 04 0A 0B 0C
78 D0 04 0A 0B 0C	78 D0 04 0A 0B 0C
78 D0 04 0A 0B 0C	78 D0 04 0A 0B 0C
78 D0 04 0A 0B 0C	78 D0 04 0A 0B 0C
78 D0 04 0A 0B 0C	78 D0 04 0A 0B 0C
78 D0 04 0A 0B 0C	78 D0 04 0A 0B 0C


MISC CRC

There are some free tools available on Internet that can be used to send a magic packet. Please refer to the following link to understand more about [Magic Packet](#).

4 System Configuration

4.1 BIOS Settings

The system is shipped with factory-default BIOS settings meticulously programmed for optimum performance and compatibility. In this section, we'll illustrate some of BIOS settings you may need to modify. Please always make sure you understand the effect of change before you proceed with any modification. If you are unsure of the function you are changing, it is recommended to change one setting at a time to see its effect(s).




NOTE


Not all BIOS settings will be discussed in this section. If a particular setting/ function you are after requires specific BIOS settings but is not discussed in this section, please contact Neousys Technical Support staff.

4.1.1 COM1 & COM3 Operating Mode

COM1 and COM3 of System series support RS-232 (full-duplex), RS-422 (full-duplex) and RS-485 (half-duplex) mode. You can set the COM1/ COM3 operating mode via BIOS settings.



Another option in BIOS called “*Slew Rate*” defines how sharp the rising/falling edge is for the output signal of COM1/ COM3. For long-distance RS-422/485 transmission, you may set the “*Slew Rate*” option as “High” to improve signal quality.




To set COM port operating mode:

1. When system boots up, press F2 to enter BIOS setup utility.
2. Go to **[Advanced] > [Peripheral Configuration]**.
3. Highlight the COM port you wish to set and press Enter to bring up setting options.
Use up/ down arrow to highlight your selection and press Enter.
4. Repeat step 2 to set other COM ports.
5. Press F10 to "Exit Saving Changes".

4.1.2 SATA Configuration

The system SATA controller supports two (2) operating modes: **AHCI** and **RAID** mode. **AHCI** mode, which exposes SATA's advanced capabilities such as hot swapping and native command queuing, is supported in several later version of operating systems. **RAID** mode provides redundant data storage (RAID 1) or a higher throughput (RAID 0). The system features built-in hardware RAID. No additional H/W or driver is needed to use RAID function.



Recommended SATA controller mode settings:

- If you're using Windows Vista, Windows 7/ 8/ 10, or Linux kernel 2.6.19 or later, you can select **AHCI** mode for better performance.
- If you're installing two 2.5" HDD/ SSD and looking for data striping (RAID 0) or data mirroring (RAID 1), you can select **RAID** mode to utilize built-in RAID.


To set SATA controller mode:

1. When system boots up, press F2 to enter BIOS setup utility.
2. Go to **[Advanced] > [SATA Configuration]**.

3. Highlight the SATA port you wish to set and press Enter to bring up setting options. Use up/ down arrow to highlight your selection and press Enter.
4. Repeat step 3 to set other SATA ports.
5. Press F10 to "Exit Saving Changes".

4.1.3 TPM Availability

Trusted Platform Module (TPM) is a hardware-based cryptoprocessor to secure hardware by integrating cryptographic keys into devices. The system is designed with on-board TPM 2.0 module. As TPM 2.0 requires 64-bit Windows 7/8/10 with UEFI boot mode, it is disable in BIOS by default. For customers who want to utilize TPM feature, you will need to enable TPM in BIOS as well as install Windows with UEFI mode.




To enable TPM availability:

1. When system boots up, press F2 to enter BIOS setup utility.
2. Go to **[Security] > [TPM Availability]**, press Enter to bring up Options, Available/ Hidden.
3. Highlight your selection, press Enter and press F10 to "Exit Saving Changes".

4.1.4 CPU SKU Power Configuration

The system supports various 6th-Gen Skylake LGA1151 CPUs. A unique feature, “**SKU Power Config**” is implemented in BIOS to allow users to specify user-defined SKU power limit. Although the system is designed to have best thermal performance with CPUs of 35W TDP, you can install a 65W CPU and limit its SKU power to obtain more computing power. This feature gives you the flexibility of CPU selection and great balance between computing power and operating temperature range.



Here is our suggestion regarding specifying SKU power for system with 65W/ 54W/ 51W CPUs.

- For system running at up to 70°C ambient, specify SKU power to 35 W.
- For system running at up to 60°C ambient, specify SKU power to 45 W.
- For system running at up to 50°C ambient, specify SKU power to Max. TDP.


To configure the CPU SKU power limit:

1. When the system boots up, press F2 to enter BIOS setup utility.
2. Go to **[Power]** → **[Power & Performance]**.

Select a proper value of SKU power limit for **[SKU Power Config]** option.

4.1.5 Wake on LAN Option

Wake-on-LAN (WOL) is a mechanism which allows you to turn on your System series via Ethernet connection. To utilize Wake-on-LAN function, you have to enable this option first in BIOS settings. Please refer "[Powering On Using Wake-on-LAN](#)" to set up the system.




To enable/disable "Wake on LAN" option:

1. When system boots up, press F2 to enter BIOS setup utility.
2. Go to **[Power] > [Wake on LAN]**.
3. Press Enter to bring up setting options, scroll to the setting you desire and press Enter to set.
4. Press F10 to "Exit Saving Changes."

4.1.6 Power On after Power Failure Option

This option defines the behavior of system when DC power is supplied.



Value	Description
S0 – Power On	System is powered on when DC power is supplied.
S5 – Power Off	System is kept in off state when DC power is supplied.

To set “Power On after Power Failure” option:

1. When system boots up, press F2 to enter BIOS setup utility.
2. Go to **[Power] > [Power On after Power Failure]**.
3. Scroll down to highlight **[Power On after Power Failure]**, press Enter to bring up setting options, S0 – Power On or S5 – Power Off, and press Enter to select the setting.
4. Press F10 to “Exit Saving Changes”

4.1.7 Boot Type (Legacy/ UEFI)

The system supports both Legacy and Unified Extensible Firmware Interface (UEFI) boot modes. UEFI is a specification proposed by Intel to define a software interface between operating system and platform firmware. Most modern operating systems, such as Windows 7/ 8/ 10 and Linux support both Legacy and UEFI boot modes. The Legacy boot mode uses MBR partition for disk and VBIOS for video initialization, the UEFI boot mode uses GPT partition which supports greater than 2TB partition size and GOP driver for faster video initialization.



It is recommended that:

- If you need greater than 2TB disk partition or want to use TPM 2.0 function, you shall choose UEFI boot mode and install operating system accordingly.
- Otherwise you can choose Legacy boot mode for most cases.

To configure Boot Type:

1. When system boots up, press F2 to enter BIOS setup utility.
2. Go to **[Boot] > [Boot Type]**, press Enter to bring up options, Dual Boot (Legacy+UEFI), Legacy Boot Type, UEFI Boot Type.
3. Highlight your selection and press Enter.
4. Press F10 to "Exit Saving Changes".

4.1.8 Boot Option for Newly Added Device

The Add Boot Options dedicates the boot sequence order of a newly added device (eg. USB flash drive). The setting allows you to set the newly added device as the first device or as the last device to boot.




To set Add Boot Options:

1. When system boots up, press F2 to enter BIOS setup utility.
2. Go to [Boot] > [Add Boot Options], press Enter to bring up options, First or Last.
3. Highlight your selection and press Enter, press F10 to "Exist Saving Changes".

4.1.9 Watchdog Timer for Booting


The system BIOS has a useful feature which allows users to use watchdog timer to ensure a successful boot process. You can specify the timeout value for watchdog timer. Once the watchdog timer expires, BIOS issues a reset command to initiate another boot process. You can also set the behavior of how to stop the watchdog timer. There are two options in BIOS menu, “**Automatically after POST**” and “**Manually after Entering OS**”. When “**Automatically after POST**” is selected, the BIOS automatically stop the watchdog timer after POST (Power-On Self Test) OK. When “**Manually after Entering OS**” is selected, it’s user’s liability to stop the watchdog timer when entering OS. This guarantees the system can always boot to OS, otherwise another booting process will be initiated. For information about programming watchdog timer, please refer to [Watchdog Timer & Isolated DIO](#).



To set the watchdog timer for boot in BIOS:

1. When system boots up, press F2 to enter BIOS setup utility.
2. Go to **[Boot]** menu.
3. Disable or select timeout value for **[WDT for Booting]** option.


4. Once you give a timeout value, the **[WDT Stop Option]** option appears. You can select “Automatically after POST” or “Manually after Entering OS”.



5. Press F10 to “Exit Saving Changes.”

4.1.10 Selecting Legacy/ UEFI Boot Device

When multiple bootable devices are connected (e.g. HDD, mSATA, USB flash disk, USB DVD-drive), you may need to select one of them as the boot device. There are two ways to select the device. You can either, press F12 when system boots up to go to Boot Manager and then select one of the devices, or select the boot device in BIOS settings.



To set boot order for devices in UEFI Boot Device:

1. When system boots up, press F2 to enter BIOS setup utility
2. Go to **[Boot] > [UEFI Boot Device]**
3. Highlight the device you wish to make boot order changes to and press F5/ F6 or +/- to change device boot order.


To select boot order for devices in Legacy Boot Device:

1. When system boots up, press F2 to enter BIOS setup utility
2. Go to **[Boot] > [Legacy Boot Device]**, you can choose the type of device to boot list by selecting "By Device" or "By Device Type".
3. Highlight the device or device category you wish to make boot order changes to and press F5/ F6 or +/- to change device boot order.


4.2 AMT Configuration

Intel® AMT (Active Management Technology) is a hardware-based technology for remotely managing target PCs via Ethernet connection. The system supports AMT function via its Ethernet port implemented with Intel I219-LM. Prior to using AMT to remotely control the system, you need to configure AMT password and network settings.

1. Make sure you have connected the proper Ethernet port (via I219-LM).



2. When the system boots up, press F10 to enter the MEBx configuration menu.



3. Highlight MEBx Login and press Enter, a prompt will appear asking for password. The default password is "admin". For further MEBx configuration details, please refer to [Intel® MEBX User Guide](#).

4.3 RAID Volume Configuration

The system supports hardware RAID function for more reliable and efficient disk access. The built-in RAID supports RAID 0 (data stripping) and RAID 1 (data mirroring). You can configure RAID mode according to your needs by following steps listed below.

1. Configure the SATA controller by going to **[Advanced] > [SATA Configuration] > [SATA Mode Selection]** and select **[RAID]** (refer to [SATA Configuration](#) for details).
2. Reboot the system once RAID mode has been set, upon reboot, you will see a UI banner for RAID configuration.

```
Intel(R) Rapid Storage Technology - Option ROM - 14.0.0.2234
Copyright (C) Intel Corporation. All rights reserved.

RAID Volumes:
None defined.

Physical Devices:
ID Device Model Serial # Size Type/Status(Vol ID)
2 Phison SSBP064GT 0757176400019671 59.6GB Non-RAID Disk
3 SATA SSD 073A092C00041319 59.6GB Non-RAID Disk
Press <CTRL-I> to enter Configuration Utility...
```

3. Press **[Ctrl + I]** to enter the RAID configuration menu. Follow the on-screen instructions to create, delete or configure the RAID volume.

```
Intel(R) Rapid Storage Technology - Option ROM - 14.0.0.2234
Copyright (C) Intel Corporation. All rights reserved.

[ MAIN MENU ]
1. Create RAID Volume
2. Delete RAID Volume
3. Reset Disks to Non-RAID
4. Recovery Volume Options
5. Acceleration Options
6. Exit

[ DISK/VOLUME INFORMATION ]
RAID Volumes:
None defined.

Physical Devices:
ID Device Model Serial # Size Type/Status(Vol ID)
2 Phison SSBP064GT 0757176400019671 59.6GB Non-RAID Disk
3 SATA SSD 073A092C00041319 59.6GB Non-RAID Disk

[↑↓]-Select [ESC]-Exit [ENTER]-Select Menu
```

5 OS Support and Driver Installation

5.1 Operating System Compatibility

The system support most operating system developed for Intel® x86 architecture. The following list contains the operating systems which have been tested by Neosys Technology.

- Microsoft Window 7 (x86*/ x64*)
- Microsoft Window 8 (x64)
- Microsoft Window 10 (x64)
- Microsoft Embedded Standard 7
- CentOS 7
- Debian 8.7**
- Fedora 24**
- OpenSUSE 42.1**
- Ubuntu 14.04.4 LTS and 16.04 LTS**



NOTE

** Due to xHCI driver is not included natively in Windows 7, you may encounter Keyboard/ mouse issues when installing Windows 7. Neosys offers a Windows-based batch file and step-by-step installation guide.*

*** For distributions, graphics driver and RAID function may not be completely implemented in its kernel. You may encounter restrictions when using these features, such as triple independent display and RAID. For optimum operation, it is the users' responsibility to manually check for new drivers and upgrades!*


Neosys may remove or update operating system compatibility without prior notice. Please contact us if your operating system of choice is not on the list.

5.2 Install Drivers Automatically

The system comes with a “Drivers & Utilities” DVD that offers “one-click” driver installation process. It automatically detects your Windows operating system and installs all necessary drivers for you system with a single click.

To install drivers automatically, please refer to the following procedures.

1. Insert the “Drivers & Utilities” DVD into a USB DVD-drive connect to your system. A setup utility launches and the following dialog appears.



2. Click on “**Automatic Driver Installation**” and the setup utility will automatically detect your Windows operating system and install all necessary drivers. The installation process takes about 6~8 minutes depending on your Windows version. Once driver installation is done, the setup utility reboots your Windows and you may begin using your system.

5.3 Install Drivers Manually

You can also manually install each driver for the system. Please note when installing drivers manually, you need to install the drivers in the following sequence mentioned below.

5.3.1 For Windows 7 (x86)

The recommended driver installation sequence is

1. Chipset driver (x:\Driver_Pool\Chipset_10_APL\Win_ALL\SetupChipset.exe)
2. Graphics driver (x:\Driver_Pool\Graphics_SKL_APL\Win_7_32\Setup.exe)
3. Audio driver (x:\Driver_Pool\Audio_ALC262\Win_ALL_32\Setup.exe)
4. LAN driver
(x:\Driver_Pool\GbE_I210_I350\Win_ALL_32\APPS\PROSETDX\Win32\DxSetup.exe)
5. ME driver (x:\Driver_Pool\ME_10_Series\Win_ALL_AMT\SetupME.exe)

5.3.2 For Windows 7 (x64)

The recommended driver installation sequence is

1. Chipset driver (x:\Driver_Pool\Chipset_10_APL\Win_ALL\SetupChipset.exe)
2. Graphics driver
(x:\Driver_Pool\Graphics_SKL_APL\Win_7_8_10_APL_64\Setup.exe)
3. Audio driver (x:\Driver_Pool\Audio_ALC262\Win_ALL_64\Setup.exe)
4. LAN driver
(x:\Driver_Pool\GbE_I210_I350\Win_ALL_64\APPS\PROSETDX\Winx64\DxSetup.exe)
5. TPM 2.0 driver
(x:\Driver_Pool\TPM2\Win7_64\Windows6.1-KB2920188-v7-x64.msu)
6. ME driver (x:\Driver_Pool\ME_10_Series\Win_ALL_AMT\SetupME.exe)

5.3.3 For Windows 8 (x86)

The recommended driver installation sequence is

1. Chipset driver (x:\Driver_Pool\Chipset_10_APL\Win_ALL\SetupChipset.exe)
2. Audio driver (x:\Driver_Pool\Audio_ALC262\Win_ALL_32\Setup.exe)
3. LAN driver
(x:\Driver_Pool\GbE_I210_I350\Win_ALL_32\APPS\PROSETDX\Win32\DxSetup.exe)
4. ME driver (x:\Driver_Pool\ME_10_Series\Win_ALL_AMT\SetupME.exe)

5.3.4 For Windows 8 (x64)

The recommended driver installation sequence is

1. Chipset driver (x:\Driver_Pool\Chipset_10_APL\Win_ALL\SetupChipset.exe)
2. Graphics driver
(x:\Driver_Pool\Graphics_SKL_APL\Win_7_8_10_APL_64\Setup.exe)
3. Audio driver (x:\Driver_Pool\Audio_ALC262\Win_ALL_64\Setup.exe)
4. LAN driver
(x:\Driver_Pool\GbE_I210_I350\Win_ALL_64\APPS\PROSETDX\Winx64\DxSetup.exe)
5. ME driver (x:\Driver_Pool\ME_10_Series\Win_ALL_AMT\SetupME.exe)

5.3.5 For Windows 10 (x32)

The recommended driver installation sequence is

1. Chipset driver (x:\Driver_Pool\Chipset_10_APL\Win_ALL\SetupChipset.exe)
2. Audio driver (x:\Driver_Pool\Audio_ALC262\Win_ALL_32\Setup.exe)
3. LAN driver
(x:\Driver_Pool\GbE_I210_I350\Win_ALL_32\APPS\PROSETDX\Win32\DxSetup.exe)
4. ME driver (x:\Driver_Pool\ME_10_Series\Win_ALL_AMT\SetupME.exe)

5.3.6 For Windows 10 (x64)

The recommended driver installation sequence is

1. Chipset driver (x:\Driver_Pool\Chipset_10_APL\Win_ALL\SetupChipset.exe)
2. Graphics driver
(x:\Driver_Pool\Graphics_SKL_APL\Win_7_8_10_APL_64\Setup.exe)
3. Audio driver (x:\Driver_Pool\Audio_ALC262\Win_ALL_64\Setup.exe)
4. LAN driver
(x:\Driver_Pool\GbE_I210_I350\Win_ALL_64\APPS\PROSETDX\Win10_x64\DxSetup.exe)
5. ME driver (x:\Driver_Pool\ME_10_Series\Win_ALL_AMT\SetupME.exe)

5.4 Install WDT_DIO Driver Package

Neosys provides a driver package which contains function APIs for watchdog timer, digital I/ O, per-port PoE power on/off control and other platform-related functions. You should install the driver package (WDT_DIO_Setup.exe) in prior to use these functions.



NOTE

Please install WDT_DIO_Setup_v2.2.8.4 or later versions for The system.

5.4.1 For Windows 7 (x86)

Please execute the driver setup program in the following directory.

x:\Driver_Pool\WDT_DIO\XP_Win7_8_32\WDT_DIO_Setup_v2.2.8.4.exe

5.4.2 For Windows 7/ 8/ 10 (x64)

Please execute the driver setup program in the following directory.

x:\Driver_Pool\WDT_DIO\Win7_8_64\WDT_DIO_Setup_v2.2.8.4(x64).exe

5.4.3 For Windows 7/ 8/ 10 (WOW64)

Please execute the driver setup program in the following directory.

x:\Driver_Pool\WDT_DIO\Win7_8_WOW64\WDT_DIO_Setup_v2.2.8.4(wow64).exe

Appendix A: Windows 7 Installation

xHCI Driver Support in Microsoft OS

Intel Skylake platform removed EHCI controller and supports USB 2.0 and USB 3.0 connectivity only through its xHCI controller. For **Windows 8/ 8.1** and **Windows 10**, xHCI controller is natively supported. To install Windows 8/ 8.1/ 10, please follow the recommended installation procedure by Microsoft. However, **Windows 7** does not natively support xHCI thus the xHCI driver needs to be manually patched in order to support both USB storage device and USB keyboard/mouse during the OS installation process.

If you would like to install Windows 7, the simplest way is to create a USB thumb drive with Windows 7 installation files and Intel xHCI driver included. Please follow instructions in the following sections to install Windows 7 on your system.

Please refer to the following procedures to create an installation flash drive to aid in smooth installation of Windows 7.

User Provided Items For Windows Installation

Before we proceed with the creation of USB flash drive for installation, please make sure you have the following items.


1. Windows 7 original installation DVD
2. USB thumb drive with at least 4 GB capacity
3. Software utility to create ISO image from DVD, e.g.
 - ImgBurn (<http://www.imgburn.com>)
 - Nero (<http://www.nero.com>)
4. Software utility to create bootable USB drive from ISO file, e.g.
 - Microsoft Windows USB/DVD Download Tool
(<https://www.microsoft.com/en-us/download/windows-usb-dvd-download-tool>)
 - ISO to USB (<http://www.isotousb.com>)
5. You should have at least 10 GB disk space on your local drive.

Creating Windows 7 Installation USB Flash Drive

Once you have all the “user provided items”, please follow the steps below to create a Windows 7 Installation USB flash drive.

Step 1 – Create .ISO File From Windows 7 DVD

The first step is to create a .iso file from the Windows 7 DVD. Here we use ImgBurn (<http://www.imgburn.com>) to create the .iso file and save it to local drive.




Step 2 – Create USB Flash Drive Installer From .ISO

The next step is to create a bootable USB flash drive using the .iso file created in step 1. Here we use Microsoft Windows USB/DVD Download Tool to create the USB flash drive

(<https://www.microsoft.com/en-us/download/windows-usb-dvd-download-tool>).

Please note that the content of USB flash drive will be destroyed.

1. Right-click on the '**Windows 7 USB DVD Download Tool**' and select '**Run as administrator**'.
2. Follow the instructions below to create the USB flash drive installer.



Microsoft Store


WINDOWS 7 USB/DVD DOWNLOAD TOOL Online help

Step 1 of 4: Choose ISO file

1.Select image

Source file: Browse

2.Click Next Next



Microsoft Store




WINDOWS 7 USB/DVD DOWNLOAD TOOL Online help

Step 2 of 4: Choose media type

Please select the media type you would like to use to create your Windows 7 backup. You can choose to copy to USB or burn to DVD.

3.Choose media to install to


Start over USB device DVD



Step 3 – Create Folder and Copy Files For Patching Process

In this step, we need to create a working folder on your local drive and copy necessary files to it. Please follow the steps below.

1. Create a temporary working folder on your local drive. Here we use D:\WIM as an example.
2. Create another folder under D:\WIM for Intel xHCI driver files. Here we use \x86 for Win7 32-bit and \x64 for Win7 64-bit.
3. Copy xHCI driver files to the corresponding folder. You can find the driver files from Neousys Driver DVD.
 - For Win7 32-bit, copy all files from
x:\Driver_Pool\USB3_10_Series\Win7_ALL\x86 to D:\WIM\x86
 - For Win7 64-bit, copy all files from
x:\Driver_Pool\USB3_10_Series\Win7_ALL\x64 to D:\WIM\x64
 (where x: denotes the drive of your DVD drive)
4. Copy **install.wim** and **boot.wim** from \sources folder of your USB flash drive to D:\WIM.



5. On the created USB drive, locate the folder
“x:\Driver_Pool\USB3_10_Series\Win7_ALL”, copy the batch file
(**Win7_USB3_Patch_x86.bat** or **Win7_USB3_Patch_x64.bat**) to the working
folder “D:\WIM”.

Step 4 – Execute .bat File to Patch .wim Files

To support xHCI for Windows 7 installation, both install.wim and boot.wim need to be patched to include xHCI driver files. Neosys offers Windows-based batch file

(**Win7_USB3_Patch_x86.bat** for Windows 7 32-bit and


Win7_USB3_Patch_x64.bat for Windows 7 64-bit) to simplify this process.

1. Before executing the batch file, please make sure folders specified in the batch file are identical to your working folders.

```
SET IMAGE_PATH=D:\WIM
```

```
SET DRIVER_PATH=D:\WIM\x86
```

```
SET DRIVER_PATH=D:\WIM\x64
```



```
Win7_USB3_Patch_x86_new - Notepad
File Edit Format View Help
@echo Specify folders of image and driver files
@echo off
SET IMAGE_PATH=D:\WIM
SET DRIVER_PATH=D:\WIM\x86
SET DRIVER_PATH=D:\WIM\x64

@echo:
@echo Specify Windows 7 Version here.

Dism /Get-WimInfo /WimFile:"%IMAGE_PATH%\install.wim"
@echo off
SET /p var=Please input the Windows 7 Version:
@echo off
SET WIN7_VERSION=%var%

md %IMAGE_PATH%\MOUNT

dism.exe /Cleanup-Mountpoints
dism.exe /Cleanup-Wim

dism.exe /Mount-WIM /WimFile:"%IMAGE_PATH%\install.wim" /index:%WIN7_VERSION% /MountDir:"%IMAGE_PATH%\MOUNT"
dism.exe /image:"%IMAGE_PATH%\MOUNT" /Add-Driver /driver:"%DRIVER_PATH%" /ForceUnsigned /recurse
dism.exe /Unmount-wim /mountdir:"%IMAGE_PATH%\MOUNT" /commit

dism.exe /Mount-WIM /WimFile:"%IMAGE_PATH%\boot.wim" /index:1 /MountDir:"%IMAGE_PATH%\MOUNT"
dism.exe /image:"%IMAGE_PATH%\MOUNT" /Add-Driver /driver:"%DRIVER_PATH%" /ForceUnsigned /recurse
dism.exe /Unmount-wim /mountdir:"%IMAGE_PATH%\MOUNT" /commit

dism.exe /Mount-WIM /WimFile:"%IMAGE_PATH%\boot.wim" /index:2 /MountDir:"%IMAGE_PATH%\MOUNT"
dism.exe /image:"%IMAGE_PATH%\MOUNT" /Add-Driver /driver:"%DRIVER_PATH%" /ForceUnsigned /recurse
dism.exe /Unmount-wim /mountdir:"%IMAGE_PATH%\MOUNT" /commit

rd %IMAGE_PATH%\MOUNT
```


2. Right click on the batch file, select “Run as administrator” and click on “Yes” to continue. A menu of various Windows 7 version options will appear, please enter the corresponding index number for your Windows 7 version and press Enter.

```

C:\Windows\System32\cmd.exe
Specify folders of image and driver files
Specify Windows 7 Version here.
Deployment Image Servicing and Management tool
Version: 10.0.10240.16384
Details for image : D:\WIM\install.wim
Index : 1
Name : Windows 7 STARTER
Description : Windows 7 STARTER
Size : 8,067,003,725 bytes
Index : 2
Name : Windows 7 HOMEBASIC
Description : Windows 7 HOMEBASIC
Size : 8,127,590,116 bytes
Index : 3
Name : Windows 7 HOMEPREMIUM
Description : Windows 7 HOMEPREMIUM
Size : 8,569,006,173 bytes
Index : 4
Name : Windows 7 PROFESSIONAL
Description : Windows 7 PROFESSIONAL
Size : 8,442,573,362 bytes
Index : 5
Name : Windows 7 ULTIMATE
Description : Windows 7 ULTIMATE
Size : 8,610,128,720 bytes
The operation completed successfully.
Please input the Windows 7 Version: 

```

3. This will automatically patch both install.wim and boot.wim to include xHCI drivers. The patch process may take a few minutes to complete.
4. Once the patch process has finished, please copy the patched “install.wim” and “boot.wim” files from your local drive to the USB flash drives’ \sources folder. A prompt may appear asking if you want to overwrite existing files, please click “Yes” and continue.



Step 5 – Install Windows 7 Using USB Flash Drive Installer


Now you can use the USB flash drive to install Windows 7 on your system.

1. Plug the USB flash drive to USB port.
2. Power on the system and press F12 to select USB flash drive as boot device.
3. Follow regular installation process to install Windows 7 on your system. The xHCI driver is included in the newly-installed system.



NOTE

If it appears a warning message of “Setup was unable to create a new system partition or locate an existing system partition”, please unplug and re-plug the USB flash drive, click ‘Refresh’ and try again.



Appendix B: Using WDT & DIO

The watchdog timer (WDT) function ensures reliable system operation. The WDT is a hardware mechanism to reset the system if the watchdog timer expires. Users can start the WDT and keep resetting the timer to make sure the system or program is running. Otherwise, the system shall be reset.

In this section, we'll illustrate how to use the function library provided by Neosys to program WDT functions. Currently, WDT driver library supports Windows 7/ 8.1/ 10 32-bit and 64-bit versions. For other OS support, please contact Neosys Technology for further information.

Installing WDT_DIO Library


The WDT_DIO function library is delivered in the form of a setup package named **WDT_DIO_Setup.exe**. Prior to programming WDT, you should execute the setup program and install the WDT library. Please use the following WDT_DIO_Setup packages according to your operating system and application.

- For Windows 7/ 8.1/ 10 32-bit OS, please install WDT_DIO_Setup_v2.2.7.9.exe or later version.
- For Windows 7/ 8.1/ 10 64-bit OS with 64-bit application (x64 mode), please install WDT_DIO_Setup_v2.2.7.9(x64).exe or later version.
- For Windows 7/ 8.1/ 10 64-bit OS with 32-bit application (WOW64 mode), please install WDT_DIO_Setup_v2.2.7.9(wow64).exe or later version.


WDT and DIO Library Installation

To setup WDT & DIO Library, please follow instructions below.


1. Execute **WDT_DIO_Setup.2.2.7.9.exe**. and the following dialog appears.



2. Click "Next >" and specify the directory of installing related files. The default directory is *C:\Neosys\WDT_DIO*.



3. Once the installation has finished, a dialog will appear to prompt you to reboot the system. The WDT & DIO library will take effect after the system has rebooted.



4. When programming your WDT or DIO program, the related files are located in

Header File:	\Include
Library File:	\Lib
Function Reference:	\Manual
Sample Code:	\Sample\WDT_Demo (Demo for Watchdog Timer) \Sample\DIO_Demo (Demo for DIO Control) \Sample\COS_Demo (Demo for change-of-state DI) \Sample\CAN_Demo (Demo for CAN bus manipulation) \Sample\IGN_Demo (Demo for ignition status manipulation) \Sample\POE_Demo (Demo for PoE per-port on/off control)

□□

WDT Function Reference

InitWDT

Syntax	BOOL InitWDT(void);
Description:	Initialize the WDT function. You should always invoke InitWDT() before set or start watchdog timer.
Parameter	None
Return Value	TRUE: Successfully initialized FALSE: Failed to initialize
Usage	<pre> BOOL bRet = InitWDT() </pre>

SetWDT

Syntax	BOOL SetWDT(WORD tick, BYTE unit);
Description	Set timeout value and unit for watchdog timer. When InitWDT() is invoked, a default timeout value of 255 seconds is assigned.
Parameter	<i>tick</i> WORD value (1 ~ 65535) to indicate timeout ticks. <i>unit</i> BYTE value (0 or 1) to indicate unit of timeout ticks. 0 : unit is minute 1: unit is second
Return Value	If value of unit is correct (0 or 1), this function returns TRUE, otherwise FALSE.
Usage	<pre> WORD tick=255; BYTE unit=1; //unit is second. BOOL bRet = SetWDT(tick, unit); //timeout value is 255 seconds </pre>

StartWDT

Syntax	BOOL StartWDT(void);
Description	Starts WDT countdown. Once started, the WDT LED indicator will begin blinking. If ResetWDT() or StopWDT is not invoked before WDT countdowns to 0, the WDT expires and the system resets.
Parameter	None
Return Value	If the timeout value is given in correct format (WDT started), this function returns TRUE, otherwise FALSE
Usage	<pre> BOOL bRet = StartWDT() </pre>

ResetWDT

Syntax	BOOL ResetWDT(void);
Description	Reset the timeout value to the value given by SetWDT().If ResetWDT() or StopWDT is not invoked before WDT countdowns to 0, the WDT expires and the system resets.
Parameter	None
Return Value	Always returns TRUE
Usage	<pre> BOOL bRet = ResetWDT() </pre>


StopWDT

Syntax	BOOL StopWDT(void);
Description	Stops the countdown of WDT. When WDT has stopped, the WDT LED indicator stops blinking.
Parameter	None
Return Value	Always returns TRUE
Usage	<pre> BOOL bRet = StopWDT() </pre>


Using DIO Function

Wiring for DIO


The digital input function of System series is implemented using a photo-coupler with a internally series-connected 1k Ω resistor. You need to provide a voltage to specify the logic high/low state. The input voltage for logic high is 5~24V, and the input voltage for logic low is 0~1.5V.



The digital output function of System series is implemented using Power MOSFET + Analog Device iCoupler® component. The DO channels are configured as NO (normally-open) configuration. When you turn on system, all DO channels have a deterministic state of logic 0 (circuit disconnected from GND return). When logic 1 is specified, MOSFET is activated and GND return path is established. The digital output function on System series supports sinking current connection. The following diagrams are the suggested wiring for DO:



DIO Pin Definition



Pin No.	Definition	I/O	Description
1	ISO_DI3H	I	Digital input channel 3
2	ISO_DI2H	I	Digital input channel 2
3	ISO_DI1H	I	Digital input channel 1
4	ISO_DI0H	I	Digital input channel 0
5	Reserved	-	Reserved pin. Keep unconnected
6	Reserved	-	Reserved pin. Keep unconnected
7	ISO_DO3	O	Digital output channel 3
8	ISO_DO2	O	Digital output channel 2
9	ISO_DO1	O	Digital output channel 1
10	ISO_DO0	O	Digital output channel 0
11	VDD	-	DO voltage source input for inductive load
12	ISO5V	-	Isolated 5V power supply
13	Reserved	-	Reserved pin. Keep unconnected
14	ISO_DI3L	-	Digital input channel 3 GND
15	ISO_DI2L	-	Digital input channel 2 GND
16	ISO_DI1L	-	Digital input channel 1 GND
17	ISO_DI0L	-	Digital input channel 0 GND
18	Reserved	-	Reserved pin. Keep unconnected
19	Reserved	-	Reserved pin. Keep unconnected
20	DOGND	-	Digital output GND
21	DOGND	-	Digital output GND
22	DOGND	-	Digital output GND
23	DOGND	-	Digital output GND
24	DOGND	-	Digital output GND
25	DOGND	-	Digital output GND

DIO Function Reference

InitDIO

Syntax	BOOL InitDIO(void);
Description:	Initialize the DIO function. You should always invoke InitDIO() before write/read any DIO port/channel.
Parameter	None
Return Value	TRUE: Successfully initialized FALSE: Failed to initialize
Usage	<pre> BOOL bRet = InitWDT() </pre>

DReadLine

Syntax	BOOL DReadLine(BYTE ch);
Description:	Read a single channel of isolated digital input.
Parameter	<i>ch</i> BYTE value specifies the DI channel to be read. <i>ch</i> should be a value of 0 ~ 3.
Return Value	The status (TRUE or FALSE) of the specified DI channel.
Usage	<pre> BYTE ch=3; //DI channel #3 BOOL DIChValue = DReadLine(ch); //read DI channel #3 </pre>

DReadPort

Syntax	WORD DReadPort(void);
Description:	Read the entire isolated digital input port (4 channels).
Parameter	None
Return Value	The status (TRUE or FALSE) of the specified DI channel.
Usage	<pre> WORD DIPortValue = DReadPort (); </pre>

DOWriteLine

Syntax	void DOWriteLine(BYTE ch, BOOL value);
Description:	Write a single channel of isolated digital output.
Parameter	<p><i>ch</i> BYTE value specifies the DO channel to be written. <i>ch</i> should be a value of 0 ~ 3.</p> <p><i>value</i> BOOL value (TRUE or FALSE) specifies the status of DO channel.</p>
Return Value	None
Usage	<pre> BYTE ch=3; //DI channel #3 BOOL DOChValue=TRUE; DOWriteLine(ch, DOChValue); //write DO channel #3 as TRUE </pre>

DOWritePort

Syntax	void DOWritePort(WORD value);
Description:	Write the entire isolated digital output port (4 channels).
Parameter	<p><i>value</i> WORD value specifies the status of the DO port. <i>value</i> should be a value of 0~15.</p>
Return Value	None
Usage	<pre> WORD DOPortValue=0x0C; //1100b DOWritePort(DOPortValue); //write DO port as 1100b </pre>

DOWriteLineChecked

Syntax	void DOWriteLineChecked(BYTE ch, BOOL value);
Description:	Write a single channel of isolated digital output and read-back the value of DO register. Note that this function is not returned until the DO register is checked and identical to the written value.
Parameter	<i>ch</i> BYTE value specifies the DO channel to be written. <i>ch</i> should be a value of 0 ~ 3. <i>value</i> BOOL value (TRUE or FALSE) specifies the status of DO channel.
Return Value	None
Usage	BYTE ch=3; //DI channel #3 BOOL DOChValue=TRUE; DOWriteLineChecked(ch, DOChValue); //write DO channel #3 as TRUE

DOWritePortChecked

Syntax	void DOWritePortChecked(WORD value);
Description:	Write the entire isolated digital output port (8 channels) and check it has been done. Note that this function is not returned until the write value has been checked the same with the device registry.
Parameter	<i>value</i> WORD value specifies the status of the DO port. <i>value</i> should be a value of 0~15.
Return Value	None
Usage	WORD DOPortValue=0x0C; //1100b DOWritePortChecked(DOPortValue); //write DO port as 1100b

COS Function Reference

SetupDICOS

Syntax	<pre> BOOL SetupDICOS(COS_INT_SETUP *lpSetup, DWORD cbSetup); </pre>
Description	Setup Digital-Input(DI) Change-of-State(COS) interrupt parameters.
Parameter	<p><i>lpSetup</i> [in]</p> <p>A pointer to a COS_INT_SETUP structure that contains the COS configuration information for the DI device.</p> <p>This data structure contains the following variables:</p> <p><i>portMask</i></p> <p>WORD value specifies the interrupt mask for corresponding channel(s).</p> <p><i>edgeMode</i></p> <p>WORD value specifies that interrupt is generated when level change (set to 0) or on rising/falling edge (set to 1) for the corresponding channel(s).</p> <p><i>edgeType</i></p> <p>WORD value specifies that interrupt is generated on rising edge (set to 0) or falling (set to 1) edge for corresponding channel(s). This value is neglected if <i>edgeMode</i> is set to 0 for the corresponding channel(s).</p> <p><i>cbSetup</i> [in]</p> <p>The length of the structure, in bytes. The caller must set this member to size of (COS_INT_SETUP).</p>
Return Value	<p>TRUE if setup successes</p> <p>FALSE if setup failed</p>
Usage	<pre> COS_INT_SETUP setup; memset(&setup, 0, sizeof(setup)); setup.portMask = 0x0f; // enable ch.0~3 setup.edgeMode = 0; // level setup.edgeType = 0x00; // Lo/Hi BOOL bRet = SetupDICOS(&setup, sizeof(setup)); </pre>

RegisterCallbackDICOS

Syntax	BOOL RegisterCallbackDICOS(COS_INT_CALLBACK callback);
Description:	Registers a callback function, which is called when the DICOS interrupt occurred.
Parameter	<i>callback</i> [in] Specifies the callback function. The prototype for this function is described as follow. void __stdcall callback_func(COS_INT_CALLBACK_ARG* arg);
Return Value	TRUE if setup successes, FALSE if setup failed.
Usage	<pre>void __stdcall callback_func(COS_INT_CALLBACK_ARG* arg) { printf("data=0x%02x, flag=0x%02x, seq=%02d\n", arg->portData, arg->intrFlag, arg->intrSeq); } BOOL bRet = RegisterCallbackDICOS(callback_func);</pre>

StartDICOS

Syntax	BOOL StartDICOS(void);
Description	Start DI Change-of-State interrupt
Parameter	None
Return Value	TRUE if start procedure successes FALSE if start procedure failed
Usage	BOOL bRet = StartDICOS();

StopDICOS

Syntax	BOOL StopDICOS(void);
Description	Stop DI Change-of-State interrupt
Parameter	None
Return Value	TRUE if stop procedure successes FALSE if stop procedure failed
Usage	BOOL bRet = StopDICOS();

DI COS Example

```
#include <stdio.h>
#include <stdlib.h>
#include <windows.h>
#include "WDT_DIO.h"

//Step 0, define a Change-of-State Interrupt callback function
void __stdcall callback_function(COS_INT_CALLBACK_ARG* arg)
{
    printf("data=0x%02x, flag=0x%02x, seq=%02d\n",
        arg->portData, arg->intrFlag, arg->intrSeq);
}

int main(int argc, char* argv[])
{
    //Step 1, initialize DIO library by invoking InitDIO()
    if ( ! InitDIO() )
    {
        printf("InitDIO --> FAILED\n");
        return -1;
    }
    printf("InitDIO --> PASSED\n");

    //Step 2, setup Change-of-State Interrupt mask and level/edge mode
    COS_INT_SETUP setup;
```

```
memset(&setup, 0, sizeof(setup));

setup.portMask = 0x0f;      // 00001111b, enable ch.0~3
setup.edgeMode = 0x00;      // generate interrupt on level change
setup.edgeType = 0x00;      // rising/falling edge, only effective when
edgeMode = 1

if ( ! SetupDICOS(&setup, sizeof(setup)) )
{
    printf("SetupDICOS --> FAILED\n");
    return -2;
}
printf("SetupDICOS --> PASSED\n");

//Step 3, register the callback function
if ( ! RegisterCallbackDICOS(callback_function) )
{
    printf("RegisterCallbackDICOS --> FAILED\n");
    return -3;
}
printf("RegisterCallbackDICOS --> PASSED\n");

//Step 4, start the DI Change-of-State Interrupt
if ( ! StartDICOS() )
{
    printf("StartDICOS --> FAILED\n");
    return -4;
}
printf("StartDICOS --> PASSED\n");

printf("\npress any key to stop...\n");
system("pause >nul");

//Step 5, stop the DI Change-of-State Interrupt operation
if ( ! StopDICOS() )
{
    printf("StopDICOS --> FAILED\n");
```

```
        return -5;
    }
    printf("StopDICOS --> PASSED\n");

    printf("\npress any key to exit...\n");
    system("pause >nul");
    return 0;
}
```


Appendix C: PoE On/ Off Control

The system offers 802.3at PoE+ ports with a unique feature to allow users manually turn on or off the power supply of each PoE port. This can be function can be useful in power device (PD) fault-recovery or power reset.

The function APIs are encapsulated in Neousys WDT_DIO driver package. Please follow the instructions in [Appendix B Watchdog Timer & Isolated DIO](#) to install the driver package prior to programming PoE on/off control function.


GetStatusPoEPort

Syntax	BYTE GetStatusPoEPort (Byte port);
Description	Get current on/off status of designated PoE port.
Parameter	<i>port</i> BYTE value specifies the index of PoE port. Please refer to the following illustration, <i>port</i> should be a value of 3 ~ 6.
Return Value	BYTE value indicating PoE on/off status 0 if port is disabled (off) 1 if port is enabled (on)
Usage	BYTE bEnabled = GetStatusPoEPort (3); //Get on/off status of PoE Port#3




EnablePoEPort

Syntax	BOOL EnablePoEPort (BYTE port);
Description	Turn on PoE power of designated PoE port.
Parameter	<i>port</i> BYTE value specifies the index of PoE port. Please refer to the following illustration, <i>port</i> should be a value of 3 ~ 6.
Return Value	TRUE if enabled success FALSE if fail to enable.
Usage	BOOL bRet = EnablePoEPort (3); //Turn on PoE Port#3




DisablePoEPort

Syntax	BOOL DisablePoEPort (BYTE port);
Description	Turn off PoE power of designated PoE port
Parameter	<i>port</i> BYTE value specifies the index of PoE port. Please refer to the following illustration, <i>port</i> should be a value of 3 ~ 6
Return Value	TRUE if disabled success FALSE if fail to disable
Usage	BOOL bRet = DisablePoEPort (3); //Turn off PoE Port#3




Appendix D: DTIOv2 Programming Guide

Nuvis-5306RT is a state-of-the-art vision controller featuring I/O functions designed for machine vision applications, including LED lighting control, camera trigger, QEI input, PWM output and isolated DIO. To allow comprehensive control of MCU, Neousys designs two versions of Nuvis-5306RT. The one is NuMCU version and the other one is DTIOv2 version. This document is prepared for DTIOv2 version.



In DTIOv2 version, users don't need to understand MCU and can develop windows application based on WDT_DIO driver library to control the machine vision system. It is easier to control vision I/O. I will introduce more in the following paragraphs.




Programming Under Windows Environment

We provide DTIOv2 library so users can program under windows environment easily.


Users should setup environment before starting programming.


Step 1. WDT_DIO Library Installation

Please download the WDT_DIO_Setup_v2.2.7.9 or later version of WDT_DIO library from our website and install it. Please follow the steps below to complete the installation.




Choose the directory you wish to install WDT_DIO library to.






Restart the computer to complete the installation.




Step 2. Install Integrated Development Environment (IDE)

Choose your preferred integrated development environment (IDE) to install. For demonstration, we will be using Visual Studio 2017 to compile our sample code.




Step 3: Startup Visual Studio

Startup Visual Studio and open the file “5306RTDemo” in the supplied sample code.




Step 4: Execute 5306RTDemo.cpp file

A “Solution Explorer” window should appear on the right and click on “5306RTDemo.cpp”.




Step 5: Build Solution

Go to “Build > Build Solution”.




Step 6: Execute Local Windows Debugger

Click on “Local Windows Debugger”



Step 7: Pre-configured Solution

There are 10 sample programs in the pre-configured solution. You can choose the solution you wish to access by entering the number designation.



```
C:\Users\6108A1\Desktop\5306RTDemo_Sample Code\x64\Release\5306RTDemo.exe
Please select mode
0 :Leave
1 :LEDControl
2 :PWMControl
3 :TimeBasedDT2
4 :QEIEncoderRead
5 :DT2PositionTrigger
6 :SoftwareTriggerDT2
7 :BufferTriggerDT2
8 :QEIGetDirection
9 :externalInputDT2
10:triggerOutAsSource
5_
```



Nuvis-5306RT Vision-Specific I/O: TB-10 Pin Assignment



Signal		ISO5V				ISOGND	PHA	PHB	ISOGND	DI4L	DI4H	DI5L	DI5H	DI6L	DI6H	DI7L	DI7H
Pin	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68
Pin	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34
Signal		DOGND				ISOGND	IDX			DI0L	DI0H	DI1L	DI1H	DI2L	DI2H	DI3L	DI3H
Signal	LED0+	LED0-	LED1+	LED1-	DOGND	DO0	DOGND	DO1	DOGND	DO2	DOGND	DO3	VDD	DOGND	TRIG0	DOGND	TRIG1
Pin	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
Pin	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51
Signal	LED2+	LED2-	LED3+	LED3-	DOGND	DO4	DOGND	DO5	DOGND	DO6	DOGND	DO7	ISO5V	DOGND	TRIG2	DOGND	TRIG3

Vision-Specific I/O Function Description

Signal	Function Description
LED0+/ LED0- LED1+/ LED1- LED2+/ LED2- LED3+/ LED3-	<p>LED driving output</p> <p>LED0~LED3 are used to directly drive LED lights in the vision system. Each channel can be configured to output 24V constant voltage or user-programmable, up to 2A constant current to drive either CV or CC LED light using DTIO or NuMCU library. The LED driving output also supports digital dimming control by adjusting duty cycle from 0 to 100%. When connecting LED lights, wire LED+ to positive polarity (anode) and LED- to negative polarity (cathode).</p> <p>Note</p> <p><i>Total power budget for four LED output channels is limited to 80W. Users shall cautiously program the LED outputs and make sure all connected LED lights consume less than 80W at the same time.</i></p>
DO0/ DOGND DO1/ DOGND DO2/ DOGND DO3/ DOGND	<p>Isolated digital output (high-current)</p> <p>DO0~DO3 are open-drained DO channels designed to control external actuator devices, such as relay, valve and motor. Each channel can carry up to 24VDC, 1A rated current.</p>
DO4 (PWM0)/ DOGND DO5 (PWM1)/ DOGND DO6 (PWM2)/ DOGND DO7 (PWM3)/ DOGND	<p>Isolated digital output (high-speed) or PWM output</p> <p>DO4~DO7 are open-drained DO channels implemented using Darlington transistors. It offers <1us propagation delay and is ideal for high-speed signals such as triggers. Users can also configure these channels as PWM function in DTIO or NuMCU to generate PWM signals (external voltage source required). Each channel can carry up to 24VDC, 50mA rated current.</p>
TRIG0/ DOGND TRIG1/ DOGND TRIG2/ DOGND TRIG3/ DOGND	<p>12V camera trigger output</p> <p>TRIG0~TRIG3 are camera trigger output channels that offer isolated 12V output (push-pull DO). Users can simply wire TRIGx and DOGND to camera's trigger-in/GND directly without the need of external voltage source. Each channel can offer maximal 50mA current output with <1us propagation delay.</p>
DI0H/DI0L DI1H/DI1L DI2H/DI2L DI3H/DI3L DI4H/DI4L	<p>Isolated digital input</p> <p>DI0~DI7 are opto-isolated channels for digital input. Each channel has separated ground pin so users shall wire DI signal to DIxH and DIxL. The isolated DI is logic low when input voltage is 0~1.5V and logic high when input voltage is 5~24V.</p>

DI5H/DI5L DI6H/DI6L DI7H/DI7L																																	
PHA PHB IDX ISOGND	<p>Quadrature encoder input</p> <p>PHA, PHB and IDX are pins for quadrature encoder input. It support either single-ended encoder or differential encoder by jumper selection. Please refer to the following table for correctly wire your quadrature encoder.</p> <table><tr><th colspan="2">Single-ended encoder</th><th colspan="2">Differential encoder</th></tr><tr><th>Pin#</th><th>Wire to encoder's</th><th>Pin#</th><th>Wire to encoder's</th></tr><tr><td>57</td><td>GND</td><td>57</td><td>A-</td></tr><tr><td>58</td><td>A</td><td>58</td><td>A+</td></tr><tr><td>59</td><td>B</td><td>59</td><td>B+</td></tr><tr><td>60</td><td>GND</td><td>60</td><td>B-</td></tr><tr><td>23</td><td>GND</td><td>23</td><td>Z-</td></tr><tr><td>24</td><td>Z</td><td>24</td><td>Z+</td></tr></table> <div></div>	Single-ended encoder		Differential encoder		Pin#	Wire to encoder's	Pin#	Wire to encoder's	57	GND	57	A-	58	A	58	A+	59	B	59	B+	60	GND	60	B-	23	GND	23	Z-	24	Z	24	Z+
	Single-ended encoder		Differential encoder																														
	Pin#	Wire to encoder's	Pin#	Wire to encoder's																													
	57	GND	57	A-																													
58	A	58	A+																														
59	B	59	B+																														
60	GND	60	B-																														
23	GND	23	Z-																														
24	Z	24	Z+																														

Programming with DTIOv2

Library

Neosys' DTIO technology offers a simple way to program real-time I/O operations with WDT_DIO library. Users can write and run C++ program based on our APIs under windows environment. It will shorten the developing time compared with programming MCU. In this document, we will introduce the concept of DTIOv2 and demonstrate some sample programs to help users easier to use Nuvis-5306RT.

LED Brightness

Users need not purchase additional LED controllers to turn on/ off LEDs as LED drivers are included in our product.

Adjust the Brightness of LED

An API is provided for users to access the LED controller. There are three LED modes to indicate different statuses.

Mode	Description
Constant current (CC)	User can adjust the brightness of LED by changing the constant current intensity. The unit of this variable is mA. The max output current is 2000 mA.
Constant voltage (CV)	We provide constant 24V in this mode and adjust the brightness of LED by modifying duty cycle.
Constant current with duty cycle (CD)	User can adjust the brightness of LED by changing the constant current intensity and modifying duty cycle at the same time.

LED Function Reference

LED_SetCurrentDriving

Syntax	BOOL __cdecl LED_SetCurrentDriving(DWORD mode, DWORD data);																			
Description	Adjust the brightness of each LED channel																			
Parameter	<p>mode [in]</p> <p>The LED mode is based on a 32 bits parameter. From 16th to 19th bit, are used to assign LED channel. If the 16th bit is set as 1, LED 0 will be configured. If the 17th bit is set as 1, LED1 will be configured, and so on.</p> <p>The second half of 32 bits parameter is used to configure mode. There are 4 LED brightness modes.</p> <table><tr><th>Mode</th><th>Value</th></tr><tr><td>disabled</td><td>0x00</td></tr><tr><td>constant current</td><td>0x01</td></tr><tr><td>constant voltage</td><td>0x02</td></tr><tr><td>constant current with duty cycle</td><td>0x03</td></tr></table> <p>data [in]</p> <p>Specifies the value to driving LED. The meaning of data is different in different mode.</p> <table><tr><th>Mode</th><th>Unit</th></tr><tr><td>constant current</td><td>mA</td></tr><tr><td>constant voltage</td><td>Percentage of duty cycle</td></tr><tr><td>constant current with duty cycle</td><td>31~16bits: mA 15 ~0 bits: Percentage of duty cycle</td></tr></table>		Mode	Value	disabled	0x00	constant current	0x01	constant voltage	0x02	constant current with duty cycle	0x03	Mode	Unit	constant current	mA	constant voltage	Percentage of duty cycle	constant current with duty cycle	31~16bits: mA 15 ~0 bits: Percentage of duty cycle
Mode	Value																			
disabled	0x00																			
constant current	0x01																			
constant voltage	0x02																			
constant current with duty cycle	0x03																			
Mode	Unit																			
constant current	mA																			
constant voltage	Percentage of duty cycle																			
constant current with duty cycle	31~16bits: mA 15 ~0 bits: Percentage of duty cycle																			
Return Value	Returns TRUE if operation successful, FALSE if operation failed.																			
Usage	<pre>DWORD pins = (0x00010000)<< 0; DWORD mode = (pins) 0x01; if (LED_SetCurrentDriving(mode,100) == false) { printf("Setting LED failed \n"); return 0; }</pre>																			

LED Example -- Turn On and Off LED

Below is an example on how to turn on and off LED. In the demonstration, the program will turn on LED0 for 10 seconds and then turn off the LED0.

```
int LEDControl ()
{

    //Set to config LED0
    DWORD pins = (0x00010000)<< 0;
    //Set LED Mode as constant current
    DWORD mode = (pins) | LED_MODE_CC;

    // Set constant current as 100 mA. It means that LED is turned on.
    if (LED_SetCurrentDriving(mode,100) == false)
    {
        printf("Setting LED failed \n");
        return 0;
    }

    Sleep(10000);

    // Set constant current as 0 mA. It means that LED is turned off .
    if (LED_SetCurrentDriving(LED_DISABLE,0) == false)
    {
        printf("Setting LED failed \n");
        return 0;
    }

    return 0;
}
```

Quadrature Encoder Interface (QEI)

The Concept of QEI

A Quadrature Encoder is known as a 2-channel incremental encoder. It converts linear /rotation displacement into a pulse signal. You can track the position and the direction of rotation by monitoring the number of pulses and the relative phase of two signals. In addition, the third channel, index channel is used to reset the position counter.

Signal Operation Modes

The QEI module supports two modes of the signal operation, quadrature phase mode and clock/ direction mode. In **quadrature phase mode**, the encoder produces two clock signals that are 90 degrees out of phase. The edge relationship is used to determine the direction of rotation. In **clock/ direction mode**, the encoder produces a clock signal to indicate steps and the other clock signal to indicate the direction of the rotation.

Capture Mode

If you set quadrature phase mode, there are two capture modes user can choose, capture modes A and B. Capture mode A can be set to update the position counter on every edge of phase A. Capture A and B mode can be set to update the position on every edge of phase A and B. For example, if the pulse is 1000 Hz, the first mode will count 2000 times per second and the second mode will count 4000 times per second.

The max position

A quadrature encoder keeps sending pulse signal to MCU and MCU keeps accumulating position counter. When the value of the position counter is equal to the max position, the position counter will reset to zero.

Index channel

Some 2-channel incremental encoders provide additional channel called index channel (z signal). It will send pulse when reset point is reached. If you set "QEI_CONFIG_RESET_IDX" flag, QEI will reset per revolution.

Swap

Two phase signals, phase A and B can be swapped before being interpreted by QEI module in order to change forward or backward definition. It can also be used to correct miss-wiring of the system.

QEI Function Reference

QEI_Setup

Syntax	BOOL __cdecl QEI_Setup(DWORD idx, QEI_SETUP *lpSetup, DWORD cbSetup);	
Description	Setup parameters used in the specified QEI controller	
Parameter	idx [in] Specify the index of QEI controllers. Currently there is only one QEI controller, so always configure 0.	
	lpSetup [in] A pointer to a QEI_SETUP structure that contains the QEI configuration. This data structure contains the following variables:	
	config [in] DWORD value specifies the configuration for the quadrature encoder.	
	Mode	Value
	QEI_CONFIG_CAPTURE_A (0x00000000)	Only count on phase A
	QEI_CONFIG_CAPTURE_A_B (0x00000008)	Count on phase A and phase B
	QEI_CONFIG_NO_RESET (0x00000000)	Do not reset position on index pulse
	QEI_CONFIG_RESET_IDX (0x00000010)	Reset position on index pulse
	QEI_CONFIG_QUADRATURE (0x00000000)	Phase A and phase B are quadrature
	QEI_CONFIG_CLOCK_DIRECTION (0x00000004)	Phase A and phase B are clock and direction
	QEI_CONFIG_NO_SWAP (0x00000000)	Do not swap phase A and phase B
	QEI_CONFIG_SWAP (0x00000002)	Swap phase A and phase B
QEI_CONFIG_CAPTURE_A (0x00000000)	Only count on phase A	

	<p>maxPos [in] DWORD value specifies the maximum position value.</p> <p>velPeriod [in] DWORD value specifies the number of clock ticks over which to measure the velocity. Set 0 value to disable velocity function.</p> <p>velPreDiv [in] DWORD value specifies the pre-divider applied to the input quadrature signal before it is counted.</p> <p>cbSetup [in] The length of the structure, in bytes. The caller must set this parameter to size of (QEI_SETUP).</p>
Return Value	Returns TRUE if setup successful, FALSE if setup failed.
Usage	<pre> QEI_SETUP QSetup; memset(&QSetup, 0, sizeof(QSetup)); QSetup.config = QEI_CONFIG_CAPTURE_A_B QEI_CONFIG_RESET_IDX QEI_CONFIG_QUADRATURE QEI_CONFIG_NO_SWAP; QSetup.maxPos = 4000; QSetup.velPeriod = 0; QSetup.velPreDiv = QEI_VEL_DIV_1; if (!QEI_Setup(0, &QSetup, sizeof(QSetup))) { printf("QEI_Setup failed \n"); return 0; } </pre>


QEI_Start

Syntax	BOOL __cdecl QEI_Start(DWORD idx);
Description	Startup QEI controller operation.
Parameter	idx [in] Specifies the index of QEI controller. By default, there is only one QEI controller and therefore, always configure 0.
Return Value	Returns TRUE if setup successful, FALSE if setup failed.
Usage	<pre>// Start QEI controller if (! QEI_Start(0)) { printf("QEI_Start failed \n"); return 0; }</pre>

QEI_Stop

Syntax	BOOL __cdecl QEI_Stop(DWORD idx);
Description	Stops QEI controller operation
Parameter	idx [in] Specifies the index of QEI controller. By default, there is only one QEI controller and therefore, always configure 0.
Return Value	Returns TRUE if setup successful, FALSE if setup failed.
Usage	<pre>// Stop QEI controller if (! QEI_Stop(0)) { printf("QEI_Stop failed \n"); return 0; }</pre>

QEI_GetDirection

Syntax	<pre> BOOL __cdecl QEI_GetDirection(DWORD idx, DWORD *lpDirection); </pre>
Description	<p>This function returns the rotation direction to the last memorized rotation direction setting.</p> <div style="border: 1px solid black; padding: 10px; margin-top: 10px;">  NOTE The last memorized encoder rotation direction may not be the current rotation direction. </div>
Parameter	<p>idx [in] Specifies the index of QEI controller. By default, there is only one QEI controller and therefore, always configure 0.</p> <p>lpDirection [out] Points to the DWORD value that specifies the current rotation direction. 1: If moving in the forward direction. -1: if moving in the reverse direction.</p>
Return Value	Returns TRUE if setup successful, FALSE if setup failed.
Usage	<pre> DWORD dir = 0; if (! QEI_GetDirection(0, &dir)) { printf("QEI_GetDirection failed \n"); return 0; } </pre>

QEI_GetPosition

Syntax	<pre> BOOL __cdecl QEI_GetPosition(DWORD idx, DWORD *lpPosition); </pre>
Description	This function acquires the current position of the encoder.
Parameter	<p>idx [in] Specifies the index of QEI controller. By default, there is only one QEI controller and therefore, always configure 0.</p> <p>lpDirection [out] Points to the DWORD value that specifies current position of the encoder.</p>
Return Value	Returns TRUE if setup successful, FALSE if setup failed.
Usage	<pre> DWORD dwPos = 0; if (! QEI_GetPosition(0, &dwPos)) { printf("QEI_GetPosition failed \n"); return 0; } </pre>

QEI_SetPosition

Syntax	<pre> BOOL __cdecl QEI_SetPosition(DWORD idx, DWORD position); </pre>
Description	This function sets the current position of the encoder.
Parameter	<p>idx [in] Specifies the index of QEI controller. By default, there is only one QEI controller and therefore, always configure 0.</p> <p>lpDirection [out] Value specifies current position of the encoder.</p>
Return Value	Returns TRUE if setup successful, FALSE if setup failed.
Usage	<pre> if (! QEI_SetPosition(0, 0)) { printf("QEI_SetPosition failed \n"); return 0; } </pre>

QEI Example 1-- Read Direction and Position

```
int QEIEncoderSample()
{
    // Config the data structure of QEI
    // Capture phase A and phase B signal, reset position when encounter index, don't
    swap phase      A and phase B
    // Set max position as 4000
    QEI_SETUP QSetup;
    memset(&QSetup, 0, sizeof(QSetup));
    QSetup.config = QEI_CONFIG_CAPTURE_A_B | QEI_CONFIG_RESET_IDX |
    QEI_CONFIG_QUADRATURE | QEI_CONFIG_NO_SWAP;
    QSetup.maxPos = 4000;
    QSetup.velPeriod = 0;
    QSetup.velPreDiv = QEI_VEL_DIV_1;

    if (!QEI_Setup(0, &QSetup, sizeof(QSetup)))
    {
        printf("QEI_Setup failed \n");
        return 0;
    }

    // Start QEI controller
    if (!QEI_Start(0))
    {
        printf("QEI_Start failed \n");
        return 0;
    }

    for(int i = 0; i < 30; i++)
    {
        DWORD   dwPos = 0;

        // read the Direction of the rotation
        if (!QEI_GetDirection(0, &dwPos))
        {
```

```
        printf("GetDirection fail \n");
        return 0;
    }
    printf("direction : %d \n", dwPos);

    // read the position
    if (!QEI_GetPosition(0, &dwPos))
    {

        printf("GetPosition fail \n");
        return 0;
    }

    printf("Position : %d \n", dwPos);

    //Sleep 300 ms
    Sleep(300);

}

// Start QEI controller
if (!QEI_Stop(0))
{
    printf("QEI_Stop failed \n");
    return 0;
}

return 0;
}
```

Deterministic Trigger I/O version 2 (DTIOv2)

The Concept of DTIOv2

Trigger target

The trigger target is defined as the output signal that can control other equipment, such as LED, camera and motor.

Trigger source

The trigger source is defined as the input signal that can trigger an output signal. Digital and encoder inputs are the trigger sources in DTIOv2. In addition, all trigger targets can also be configured as a trigger source.



Channel



Due to comprehensive input & output mappings, we designed “channel” to simplify the relationship of the trigger source and the trigger target. It is one-to-one mapping. There is exactly one trigger source and one trigger target in each channel.

Max quantity of channels is eight in the DTIOv2 library, so users can define eight trigger sources and trigger target mappings at most. Trigger source can be configured in multiple channels but trigger target only can be configured in one channel. The trigger and target relationship is defined in the following paragraph.

Four types of output signals

The status of output signal can be described by the pulse delay and the pulse width. In DTIO version 1, time is the only unit to tell the distance of pulse delay and pulse width. It is simple but is not accurate enough due to unstable signal conveyance speed. In order to improve the accuracy of DTIO system, we introduce QEI in DTIOv2. Now real displacement can be used to describe the distance of pulse delay and pulse width. Therefore, 2 types of unit and 2 pulse sections can create 4 modes for users to control output signals.









Trigger Mode

There are five trigger modes that can be set by user.

Trigger Mode	Description
Never	It is the initial value. It means turn off this channel.

Rising edge	
	<ol style="list-style-type: none"> 1. It means that the trigger target is triggered when the state of the trigger source changes from zero to one. 2. If the trigger source is QEI, the trigger target is triggered when the value of QEI is larger than the trigger data.

Falling edge	
	<ol style="list-style-type: none"> 1. It means that the trigger target is triggered when the state of the trigger source changes from one to zero. 2. If the trigger source is QEI, the trigger target is triggered when the value of QEI is smaller than the trigger data.



Time Unit

The basic operation concept of MCU is infinite loop. MCU will process the results of each trigger target based on trigger source in every loop. Time unit is the time interval between two continuous actions that MCU generates the result to the trigger target. We will calculate the pulse delay and pulse width based on this time unit. For example, if the time unit is 25 μs and the pulse delay is 2000, it means that pulse delay is 50 ms ($2000 \times 25 \mu\text{s}$).

The default value of time unit is 25 μs . However, users can adjust the time unit to fit their application needs. The value should be configured between 25 ~2500 μs and setting shorter time unit ($< 25 \mu\text{s}$) is not safe and may cause unexpected result.

Delta

Integer value specifies the fine-tuning factor for time unit. The value of +/- 1 means increasing / decreasing 0.0125 μs for the time unit. Default value of delta is 0.

Time Unit and Delta

We will use the simple formula to explain the relationship between time unit and delta.

We assume that Total Time Unit (TTU) is the value of time unit that applied to MCU.

Total Time Unit (TTU)


Total Time Unit (TTU) = time unit (ex: 25 μs) + delta * 0.0125

For example, time unit is equal to 25 μs , delta is equal to 10. And then We can calculate TTU and the result is 25.125 μs ($\text{TTU} = 25 + 10 \times 0.0125 = 25.125$)

Please be careful about the value of TTU. If TTU is below 25 μs or even below 0 μs , that will cause unexpected result. We didn't constrain to time unit and delta, so it is recommended calculating TTU before setting up configuration.

Active Low


When the flag of the active low is set, the state of the output signal is high during pulse delay and the output signal is low during pulse width. We will introduce about how to enable this flag in the following paragraph.



Active low Mode

Trigger Target as Trigger Source


It is the new feature we introduce in DTIOv2. User can use “the trigger target” to trigger other trigger target. For example, you can configure a channel that triggers the camera after LED0 is turned on.



Trigger target as trigger source Mode

Software Trigger

We provide 2 software trigger inputs (SI in short) and 2 software trigger outputs (SO in short) in Nvis-5306RT. User can send signals from CPU to MCU directly via SI and receive signals directly from MCU via SO.



Software Trigger

DTIOv2 Function Reference

DT2_Setup

Syntax	<pre> BOOL __cdecl DT2_Setup(DT2_SETUP *lpSetup, DWORD cbSetup); </pre>																						
Description	Sets up parameters used in the specified DTIOv2 controller.																						
Parameter	<p>DT2_SETUP [in]</p> <p>Index [in]</p> <p>Set the parameter to configure which channel to use. There are 8 channels in DTIOv2, configurable parameters are 0~7.</p> <p>modeFlag [in]</p> <p>There are 4 modes you can configure in this parameter. Set the following value to configure the mode you want. Please notice that only “active low” mode flag can be enabled with three other modes at the same time. More information will be provided in the next chapter.</p> <table border="1"> <thead> <tr> <th>Mode</th><th>Value</th></tr> </thead> <tbody> <tr> <td>Disable</td><td>0</td></tr> <tr> <td>Active Low</td><td>DT2_INIT_HIGN (0x01)</td></tr> <tr> <td>Trigger Buffer</td><td>DT2_TRIG_BUFF (0x02)</td></tr> <tr> <td>External Input (default deactivated)</td><td>DT2_TRIG_EIDD (0x04)</td></tr> <tr> <td>External Input (default activated)</td><td>DT2_TRIG_EIDA (0x08)</td></tr> </tbody> </table> <p>modeType [in]</p> <table border="1"> <thead> <tr> <th>Mode</th><th>Value</th></tr> </thead> <tbody> <tr> <td>PTT</td><td>DT2_MODE_PTT (0x00)</td></tr> <tr> <td>PTP</td><td>DT2_MODE_PTP (0x01)</td></tr> <tr> <td>PPT</td><td>DT2_MODE_PPT (0x02)</td></tr> <tr> <td>PPP</td><td>DT2_MODE_PPP (0x03)</td></tr> </tbody> </table>	Mode	Value	Disable	0	Active Low	DT2_INIT_HIGN (0x01)	Trigger Buffer	DT2_TRIG_BUFF (0x02)	External Input (default deactivated)	DT2_TRIG_EIDD (0x04)	External Input (default activated)	DT2_TRIG_EIDA (0x08)	Mode	Value	PTT	DT2_MODE_PTT (0x00)	PTP	DT2_MODE_PTP (0x01)	PPT	DT2_MODE_PPT (0x02)	PPP	DT2_MODE_PPP (0x03)
Mode	Value																						
Disable	0																						
Active Low	DT2_INIT_HIGN (0x01)																						
Trigger Buffer	DT2_TRIG_BUFF (0x02)																						
External Input (default deactivated)	DT2_TRIG_EIDD (0x04)																						
External Input (default activated)	DT2_TRIG_EIDA (0x08)																						
Mode	Value																						
PTT	DT2_MODE_PTT (0x00)																						
PTP	DT2_MODE_PTP (0x01)																						
PPT	DT2_MODE_PPT (0x02)																						
PPP	DT2_MODE_PPP (0x03)																						

trigMode [in]

Mode	Value
Never	DT2_TRIG_NEVER (0x00)
Rising edge	DT2_TRIG_RISING (0x01)
Falling edge	DT2_TRIG_FALLING (0x02)
Level	DT2_TRIG_LEVEL (0x03)
Always	DT2_TRIG_ALWAYS (0x04)

trigData [in]

This parameter configures the trigger position when QEI is set as the trigger source.

trigSrc [in]

This parameter configures the trigger source.

Digital Input

I/O	Value
DI 0	DT2_SRC_DI_00 (0x00010001)
DI 1	DT2_SRC_DI_01 (0x00010002)
DI 2	DT2_SRC_DI_02 (0x00010004)
DI 3	DT2_SRC_DI_03 (0x00010008)
DI 4	DT2_SRC_DI_04 (0x00010010)
DI 5	DT2_SRC_DI_05 (0x00010020)
DI 6	DT2_SRC_DI_06 (0x00010040)
DI 7	DT2_SRC_DI_07 (0x00010080)

Digital Output

I/O	Value
DO 0	DT2_SRC_DO_00 (0x00020001)
DO 1	DT2_SRC_DO_01 (0x00020002)
DO 2	DT2_SRC_DO_02 (0x00020004)
DO 3	DT2_SRC_DO_03 (0x00020008)
DO 4	DT2_SRC_DO_04 (0x00020010)
DO 5	DT2_SRC_DO_05 (0x00020020)
DO 6	DT2_SRC_DO_06 (0x00020040)
DO 7	DT2_SRC_DO_07 (0x00020080)

Camera Trigger Output

I/O	Value
TRIG 0	DT2_SRC_TRIG_00 (0x00020100)
TRIG 1	DT2_SRC_TRIG_01 (0x00020200)
TRIG 2	DT2_SRC_TRIG_02 (0x00020400)
TRIG 3	DT2_SRC_TRIG_03 (0x00020800)

LED Controller

I/O	Value
LED 0	DT2_SRC_LED_0 (0x00200001)
LED 1	DT2_SRC_LED_1 (0x00200002)
LED 2	DT2_SRC_LED_2 (0x00200004)
LED 3	DT2_SRC_LED_3 (0x00200008)

Software Trigger Input/ Output

I/O	Value
SI 0	DT2_SRC_SI_00 (0x40000001)
SI 1	DT2_SRC_SI_01 (0x40000002)
SO 0	DT2_SRC_SO_00 (0x80000001)
SO1	DT2_SRC_SO_01 (0x80000002)

QEI

I/O	Value
QEI	DT2_SRC_QEI_0 (0x00080001)

trigTgt [in]

This parameter configures the trigger target.

Digital Output

Mode	Value
DO 0	DT2_TGT_DO_00 (0x00020001)
DO 1	DT2_TGT_DO_01 (0x00020002)
DO 2	DT2_TGT_DO_02 (0x00020004)
DO 3	DT2_TGT_DO_03 (0x00020008)
DO 4	DT2_TGT_DO_04 (0x00020010)
DO 5	DT2_TGT_DO_05 (0x00020020)
DO 6	DT2_TGT_DO_06 (0x00020040)
DO 7	DT2_TGT_DO_07 (0x00020080)

Camera Trigger Output

I/O	Value
TRIG 0	DT2_TGT_TRIG_00 (0x00020100)
TRIG 1	DT2_TGT_TRIG_01 (0x00020200)
TRIG 2	DT2_TGT_TRIG_02 (0x00020400)
TRIG 3	DT2_TGT_TRIG_03 (0x00020800)

LED Controller

I/O	Value
LED 0	DT2_TGT_LED_0 (0x00200001)
LED 1	DT2_TGT_LED_1 (0x00200002)
LED 2	DT2_TGT_LED_2 (0x00200004)
LED 3	DT2_TGT_LED_3 (0x00200008)

Software Trigger Input/ Output

I/O	Value
SO 0	DT2_TGT_SO_00 (0x80000001)
SO1	DT2_TGT_SO_01 (0x80000002)

pulseDelay [in]

Mode	Description
PTT	Represent time of the pulse delay. Ex: pulseDelay = 1000 Pulse Delay = 1000 x time unit(default value is 25) ms
PTP	
PPT	Represent position offset of the pulse delay. Ex: pulseDelay = 1000 The distance from the trigger pointer to the rising edge of pulse is 1000 encoder units
PPP	

pulseWidth [in]

Mode	Description
PTT	Represent time of the pulse width. Ex: pulseWidth = 1000 Pulse Width = 1000 x time unit(default value is 25) ms
PPT	
PTP	Represent position offset of the pulse width Ex: pulseWidth = 1000 The distance from the rising edge to the falling edge is 1000 encoder units
PPP	

	<p>pulseData1 [in]</p> <p>It is the reserved parameter. Set 0 in all situations.</p> <p>pulseData2 [in]</p> <p>It is the reserved parameter. Set 0 in all situations.</p> <p>cbSetup [in]</p> <p>cbSetup is the length of the structure and is calculated in byte. You can use size of(DT2_SETUP) to calculate.</p>
Return Value	Returns TRUE if DT2_SETUP successful, FALSE if DT2_SETUP failed.
Usage	<pre>// Fill DT2_SETUP data struture DT2_SETUP aSetup; memset(&aSetup, 0, sizeof(aSetup)); aSetup.trigTgt = DT2_TGT_LED_0; aSetup.trigSrc = 0; aSetup.trigMode = DT2_TRIG_ALWAYS; aSetup.index = 0; aSetup.modeType = DT2_MODE_PTT; aSetup.pulseDelay = 20000; aSetup.pulseWidth = 20000; // Configure parameters of the channel if (!DT2_Setup(&aSetup, sizeof(aSetup))) { printf("DT2_Setup failed \n"); return 0; }</pre>

DT2_Start

Syntax

```
BOOL __cdecl DT2_Start(void);
```

Description	Starts DTIOv2 controller operation.
Parameter	None
Return Value	Return TRUE if DT2_Start successful, FALSE if DT2_Start procedure failed.
Usage	<pre>// Start Deterministic Trigger I/O v2 operation if (!DT2_Start()) { printf("DT2_start failed \n"); return 0; }</pre>

DT2_Stop

Syntax	BOOL __cdecl DT2_Stop(void);
Description	Stop DTIOv2 controller operation.
Parameter	None
Return Value	Return TRUE if DT2_Stop successful, FALSE if DT2_Stop procedure failed.
Usage	<pre>// Stop Deterministic Trigger I/O v2 operation if (!DT2_Stop()) { printf("DT2_Stop failed \n"); return 0; }</pre>

DT2_SetUnit

Syntax	BOOL __cdecl DT2_SetUnit(DWORD unit, int delta);
Description	Specify the time unit for DTIOv2. This function can be skipped if you

	want to use the default setting (25 μ s).
Parameter	<p>Unit [in]</p> <p>Specify the time unit in micro-second (recommended settings 25 to 2500).</p> <p>Delta [in]</p> <p>Integer value specifies the fine-tuning factor for time unit. The value of +/- 1 means increasing / decreasing 0.0125 μs for the time unit. Default value of delta is 0.</p>
Return Value	Return TRUE if DT2_SetUnit succeeded, FALSE if DT2_SetUnit failed.
Usage	<pre>// Set time unit as 20 microseconds if (!DT2_SetUnit(20, 0)) { printf("DT2_SetUnit failed \n"); return 0; }</pre>

DT2_GetUnit

Syntax	WORD __cdecl DT2_GetUnit(void);
Description	Acquire current time unit setting (in microseconds).
Parameter	None
Return Value	WORD is the data type of the return value. It represents the value of the current time unit.
Usage	WORD unit = DT2_GetUnit();

DT2_StPush

Syntax	BOOL __cdecl DT2_StPush(DWORD mask, DWORD value);
Description	Writes data to MCU via software trigger. You can write all software

	trigger inputs through this function simultaneously.
Parameter	<p>Mask[in]</p> <p>Each bit of this parameter determines whether relative software trigger input is used or not.</p> <p>If software trigger input 0 (SI0) is used, set bit 1 as 1.</p> <p>If software trigger input 1(SI1) is used, set bit 2 as 1.</p> <p>Other bits set 0 if those software trigger inputs are not used.</p> <p>Value[in]</p> <p>Each bit of this parameter represents a software trigger input. At most it can configure 32 software trigger inputs. We provide 2 software trigger inputs in DTIOv2, so we only use bit 1 and bit 2.</p>
Return Value	Return TRUE if DT2_StPush successful, FALSE if DT2_StPush failed.
Usage	<p>Set software trigger input 0 as 1.</p> <pre> if (!DT2_StPush(0x00000001, 1)) { printf("DT2_StPush failed \n"); return 0; } </pre>

DT2_StPull

Syntax	BOOL __cdecl DT2_StPull(DWORD* lpValue);
Description	Read data from MCU via software trigger. You can read all software

	trigger outputs through this function simultaneously.
Parameter	IpValue[out] A pointer to a DWORD value that specifies the software trigger outputs. Each bit of this parameter represents a software trigger output. At most it can configure 32 software trigger outputs. We provide 2 software trigger outputs in DTIOv2, so we only use bit 1 and bit 2 here.
Return Value	Returns TRUE if DT2_StPull successful, FALSE if DT2_StPull failed.
Usage	<pre> DWORD soValue = 0; if (! DT2_StPull(&soValue)) { printf("DT2_StPull failed \n"); return 0; } </pre>

DTIOv2 Programming Tips

Always Cease All Actions Before Starting Again

DO NOT execute DT2_Start when MCU is still running, unexpected errors may happen. Always execute DT2_Stop for MCU to cease all actions. Once DT2_Stop returns successful (all actions ceased), execute DT2_Start to start up again is the safe and recommended method.

Stop When You See Error Messages

Most of functions we provide are designed to return false messages when errors occur. Therefore, we recommend stopping program.

```
if (!DT2_Start())
{
    printf("DT2_start failed \n");
    return 0;
}
```

Reset All Channel When Starting DTIOv2 Program

It is recommended to reset all eight channels at the beginning of a DTIOv2 program as the system will remember the last configuration of each channel.


For example, channel 2 and channel 3 were set in previous operation. For a new operation, you only program channel 1 (without resetting previous settings), when you execute DT2_Start, channel 1, 2 and 3 will all be started. It may cause unexpected behaviors, so we suggest that a reset of all channels at the beginning of a DTIOv2 program.

```
int initialChannel()
{

    //Initialize 8 channels to avoid double definition*/
    for(int j = 0; j < 8; j++)
    {
        DT2_SETUP  zeroSetup;
        memset(&zeroSetup,0,sizeof(zeroSetup));
        zeroSetup.index = j;
        if ( ! DT2_Setup(&zeroSetup, sizeof(zeroSetup)) )
        {
            printf("Initializing DT2 channels failed \n");
            return 0;
        }
    }

    return 0;
}
```

DTIOv2 Example 1 - Infinite Pulse Train

Description	<p>This example demonstrates how to use DTIOv2 to generate an infinite pulse to trigger LED #0 in PTT mode. In this case, LED #0 will be turned off for 500 ms (20000 x 25 μs) and then turned on for 500 ms (20000 x 25 μs). The brightness of the LED is configured by constant current and set as 10 mA. DTIOv2 will be stopped after 4 seconds.</p>
Illustration reference	 <p>LED #0</p> <p>Pulse Delay: 300 ms</p> <p>Pulse Width: 300 ms</p> <p>Infinite Pulse Train</p>
Usage	<pre>int timeBaseDT2() { //Initialize configuration of 8 channels initialChannel(); // Fill DT2_SETUP data struture DT2_SETUP aSetup; memset(&aSetup, 0, sizeof(aSetup)); aSetup.trigTgt = DT2_TGT_LED_0; aSetup.trigSrc = 0; aSetup.trigMode = DT2_TRIG_ALWAYS; aSetup.index = 0; aSetup.modeType = DT2_MODE_PTT; aSetup.pulseDelay = 20000; aSetup.pulseWidth = 20000; // Configure parameters of the channel if (!DT2_Setup(&aSetup, sizeof(aSetup))) { printf("DT2_Setup failed \n"); return 0; } }</pre>

```
// Config LED0 as CC mode and set the current as 10 mA
DWORD pins = 0x00010000;
DWORD mode = (pins) | LED_MODE_CC;
if (LED_SetCurrentDriving(mode, 10) == false)
{
    printf("Setting LED failed \n");
    return 0;
}

// Start Deterministic Trigger I/O v2 operation
if (!DT2_Start())
{
    printf("Starting DT2 failed \n");
    return 0;
}

// Stop DT2 after 4 seconds


Sleep(4000);

if (!DT2_Stop())
{
    printf("Stopping DT2 failed \n");
    return 0;
}

return 0;
```

```
}
```

DTIOv2 Example 2 - Use DI to Trigger LED

Description	<p>In this example, DI #0 is the trigger source and it triggers LED #0 on the rising edge. LED #0 is the trigger target. We redefine the time unit as 30 microseconds, so the pulse delay of LED is 300 ms (10000 x 30 μs) and the pulse width of LED is 300 ms (10000 x 30 μs). The brightness of the LED is configured by constant current and set as 10 mA.</p>
Illustration reference	 <p>The diagram illustrates the timing relationship between DI #0 and LED #0. DI #0 (Digital Input #0) is shown as a pulse. LED #0 (LED #0) is shown as a pulse that starts at the rising edge of DI #0. The pulse delay is 300 ms and the pulse width is 300 ms. The diagram is titled "DI0 trigger LED0".</p>
Usage	<pre>int timeBaseDIDT2() { //Initialize configuration of 8 channels initialChannel(); // Fill DT2_SETUP data struture DT2_SETUP aSetup; memset(&aSetup, 0, sizeof(aSetup)); aSetup.trigTgt = DT2_TGT_LED_0; aSetup.trigSrc = DT2_SRC_DI_00; aSetup.trigMode = DT2_TRIG_RISING; aSetup.index = 0; aSetup.modeType = DT2_MODE_PTT; aSetup.pulseDelay = 10000; aSetup.pulseWidth = 10000; // Set time unit as 30 microseconds if (!DT2_SetUnit(30, 0)) { printf("DT2_SetUnit failed \n"); } }</pre>

```
        return 0;
    }

    // Configure parameters of the channel
    if (!DT2_Setup(&aSetup, sizeof(aSetup)))
    {
        printf("DT2_Setup failed \n");
        return 0;
    }

    // Config LED0 as CC mode and set the current as 10 mA
    DWORD pins = 0x00010000;
    DWORD mode = (pins) | LED_MODE_CC;
    if (LED_SetCurrentDriving(mode, 10) == false)
    {
        printf("Setting LED failed \n");
        return 0;
    }

    // Start Deterministic Trigger I/O v2 operation
    if (!DT2_Start())
    {
        printf("Starting DT2 failed \n");
        return 0;
    }

    // Stop DT2 after 10 seconds


    Sleep(10000);

    if (!DT2_Stop())
    {
        printf("Stopping DT2 failed \n");
        return 0;
    }

    return 0;
}
```

DTIOv2 Example 3 -- Software Trigger

Description This example demonstrates how to use software trigger input as the trigger source to trigger LED. Changing the status of the SI0 from 0 to 1 in short time is used to create the rising edge of the pulse signal. The LED #0 will be turned off for 500 ms (20000 x 25 μ s) and turned on for 500 ms(20000 x 25 μ s) after each trigger. The brightness of the LED is configured by constant current and set as 10 mA. It will trigger 5 times and stop DTIOv2 in this example.



Usage

```
int softwareTriggerDT2()
{
    /*Reset configuration of each channel.*/
    initialChannel();

    DT2_SETUP  aSetup;
    memset(&aSetup,0,sizeof(aSetup));
    aSetup.trigTgt = DT2_TGT_LED_0;
    aSetup.trigSrc = DT2_SRC_SI_00;
    aSetup.trigMode = DT2_TRIG_RISING;
    aSetup.index = 0 ;
    aSetup.modeType = DT2_MODE_PTT ;
    aSetup.pulseDelay =20000;
    aSetup.pulseWidth =20000;

    if ( ! DT2_Setup(&aSetup, sizeof(aSetup)) )
    {
        printf("DT2 Setup fail \n");
    }
}
```

```
        return 0;
    }

    // Config LED0 as CC mode and set the current as 10 mA
    DWORD pins = (0x00010000) << 0;
    DWORD mode = (pins) | LED_MODE_CC;

    if (LED_SetCurrentDriving(mode, 10) == false)
    {
        printf("Initial LED failed \n");
        return 0;
    }

    // Start Deterministic Trigger I/O v2 operation
    if (!DT2_Start())
    {
        printf("DT2_start failed \n");
        return 0;
    }

    //Change the status of SI0 from 0 -> 1 and set 1->0 to create pulse
    // We produce five times of pulse in this for loop
    for (int i = 0; i < 5; ++i)
    {
        if (!DT2_StPush(0x00000001, 0))
        {
            printf("DT2_StPush failed \n");
            return 0;
        }

        Sleep(10);

        if (!DT2_StPush(0x00000001, 1))
        {
            printf("DT2_StPush failed \n");
            return 0;
        }
    }
}
```

```
    }

    Sleep(1000);

    printf("Software trigger: %d \n", i);
}


// Stop Deterministic Trigger I/O v2 operation
if (!DT2_Stop())
{
    printf("DT2_Stop failed \n");
    return 0;
}

return 0;
}
```

DTIOv2 Example 4 - The Trigger Target as the Trigger Source

Description This example is to demonstrate how to use the trigger target as the trigger source in the other channel. In the first channel, DO #0 is triggered by SI #0 and then DO #0 is used to trigger LED #0 in the second channel. Both channels are set in PTT mode and triggers on rising edge signal.

Illustration reference



Usage

```
int triggerOutAsSource()
{
    /*Reset configuration of each channel.*/
    initialChannel();

    //Trigger DO0 by SI0 based on PTT mode
    DT2_SETUP aSetup;
    memset(&aSetup, 0, sizeof(aSetup));
    aSetup.trigTgt = DT2_SRC_DO_00;
    aSetup.trigSrc = DT2_SRC_SI_00;
    aSetup.trigMode = DT2_TRIG_RISING;
    aSetup.index = 0;
    aSetup.modeType = DT2_MODE_PTT;
    aSetup.pulseDelay = 20000;
    aSetup.pulseWidth = 20000;

    //Trigger LED0 by DO0 based on PTT mode
    DT2_SETUP aSetup2;
    memset(&aSetup2, 0, sizeof(aSetup2));
    aSetup2.trigTgt = DT2_SRC_LED_0;
```

```
aSetup2.trigSrc = DT2_SRC_DO_00;
aSetup2.trigMode = DT2_TRIG_RISING;
aSetup2.index = 1;
aSetup2.modeType = DT2_MODE_PTT;
aSetup2.pulseDelay = 20000;
aSetup2.pulseWidth = 20000;

// Configure parameters of the channel
if (!DT2_Setup(&aSetup, sizeof(aSetup)))
{
    printf("DT2_Setup fail \n");
    return 0;
}

if (!DT2_Setup(&aSetup2, sizeof(aSetup2)))
{
    printf("DT2_Setup fail \n");
    return 0;
}

// Config LED0 as CC mode and set the current as 10 mA
DWORD pins = 0x00010000;
DWORD mode = (pins) | LED_MODE_CC;
if (LED_SetCurrentDriving(mode, 10) == false)
{
    printf("Setting LED failed \n");
    return 0;
}

// Start Deterministic Trigger I/O v2 operation
if (!DT2_Start())
{
    printf("DT2_start failed \n");
    return 0;
}

//Change the status of SI0 from 0 -> 1 and set 1->0 to create pulse
```

```
// We produce five times of pulse in this for loop
for (int i = 0; i < 5; ++i)
{
    if (!DT2_StPush(0xFFFFFFFF, 0))
    {
        printf("DT2_StPush failed \n");
        return 0;
    }

    Sleep(10);

    if (!DT2_StPush(0xFFFFFFFF, 1))
    {
        printf("DT2_StPush failed \n");
        return 0;
    }

    Sleep(1000);

    printf("Software trigger: %d \n", i);
}

// Stop Deterministic Trigger I/O v2 operation
if (!DT2_Stop())
{
    printf("DT2 stop fail \n");
    return 0;
}

return 0;
}
```


Appendix E: Advanced DTIOv2

To enhance the power of DTIOv2, we provide two new features that make DTIOv2 more applicable in various industrial environments. The two features are “Trigger Buffer” and “External Input”. They will be explained in the following sections.

The Concept of Advanced DTIOv2


Trigger Buffer

Generally, the trigger target won't be interrupted during the active status. The active status is the time of pulse delay and pulse width. Therefore, before the active status ends, it will not receive any trigger signals from the trigger source. In other words, it ignores all trigger source inputs until the end of the pulse width. This mechanism will protect the trigger target to complete its work from unpredictable accidents.



With out Buffer trigger

In some cases, every pulse of the trigger source should result in relative action in the trigger target signal. Hence, we design a function called “trigger buffer” to process such actions. In order to protect the trigger target to finish its work, trigger signal will not be interrupted before the active status ends. However, the trigger buffer mechanism continues to calculate the pulse delay and pulse width in the background. Once the active status pulse width is over, the trigger target continues to perform signals of pulse delay and pulse width in the trigger buffer.



NOTE

1. **Unable to trigger buffer and “always” trigger mode at the same time.**
When the system is in “always” trigger mode, the buffer is automatically triggered and filled within a millisecond.
2. **Buffer size is 32.** If the buffer is full, the mechanism stops storing and will ignore trigger signals.

Trigger Buffer can be Applied to 8 Channels Simultaneously

External Input

In machine vision applications, image processing is the key to determine if the product is defective or not. Image processing requires powerful processing capability to make decisions within microsecond or even milliseconds. Powerful image processing units in a computer may include CPU, GPU or dedicated MCU. What is even more efficient is when we can have two or all three working side-by-side, such as the CPU performing the initial processing and sends decoded preliminary results to the dedicated MCU. This the main idea and why we developed an “External Input” feature in DTIOv2.

Nuvis-5306RT is composed of two main processing powerhouses by default, the mother board with CPU and chipset and the dedicated MCU. What we have done is built an efficient communication channel between the two so they can work hand-in-hand.

We added an additional action during the pulse delay of the trigger target. We give an index to this pulse and send information to the computer. Then the computer will send back information containing the status of this pulse within the time of the pulse delay. Sending 1 means activate pulse and sending 0 means deactivate pulse.

If MCU does not receive the status of this pulse before the end of pulse delay, it will assign the default value to the status to this pulse. We have mentioned there are two types of External Input in mode Flag. You can choose the relative flag to decide the default value.

External Input (deactivated by default)	DT2_TRIG_EIDD (0x04)
External Input (activated by default)	DT2_TRIG_EIDA (0x08)



NOTE

- 1. Unable to trigger buffer and “always” trigger mode at the same time.**
When the system is in “always” trigger mode, the buffer is automatically triggered and filled within a millisecond.
- 2. External output is only valid on the last channel.** *When configuring multiple channels, only the last channel is valid for “External Input”. Eg. If you configure channels 2, 4, 6, only channel 6 can be configured as “External Input”.*

3. **Buffer size is 32.** If the buffer is full, the mechanism stops storing and will ignore trigger signals.

Advanced DTIOv2 Function Reference

DT2_EiRegisterIndexed

Syntax	<pre> BOOL __cdecl DT2_EiRegisterIndexed(void (__stdcall *pfnHandler)(DWORD data)); </pre>
Description	It registers a function that can determine whether to send an activate pulse command or a deactivate pulse command.
Parameter	<p>pfnHandler [in]</p> <p>A point to the function that contain an argument which is DWORD.</p>
Return Value	Return TRUE if DT2_EiRegisterIndexed successful, FALSE if DT2_EiRegisterIndexed failed.
Usage	<p>Sending 1 means activate pulse and sending 0 means deactivate pulse.</p> <pre> static void __stdcall __IndexedHandler(DWORD index) { /* If the index is odd number, send 1 back. The trigger target will change the status to pulse high. If the index is even number, send 0 back. The trigger target will stay as pulse low. */ printf("data %d \n", index); if (index % 2 == 1) { if (!DT2_EiSendResult(index, 1)) { printf("DT2_EiSendResult failed \n"); } } else { if (!DT2_EiSendResult(index, 0)) { printf("DT2_EiSendResult failed \n"); } } } </pre>

```

    }

}

if (!DT2_EiRegisterIndexed(__IndexedHandler))
{

    printf("DT2_EiRegisterIndexed failed \n");
    return 0;

}

```

DT2_EiSendResult

Syntax	BOOL __cdecl DT2_EiSendResult(DWORD idx, DWORD value)
Description	Send the decision back to MCU.
Parameter	idx [in] The index of the pulse. Value [in]
Return Value	Return TRUE if DT2_EiSendResult succeeded, FALSE if DT2_EiSendResult failed.
Usage	<pre> if (!DT2_EiSendResult(index, 1)) { printf("DT2_EiSendResult failed \n"); } </pre>

Advanced DTIOv2 Example 1 - Trigger Buffer

Description	This example demonstrates that all pulses of the trigger source won't be ignored because of the trigger buffer.
Usage	<pre> int bufferTriggerDT2() { /*Reset configuration of each channel.*/ initialChannel(); // Trigger LED0 by SI0 // Enable buffer trigger flag to queue untriggering pulses before triggering LED0 DT2_SETUP aSetup; memset(&aSetup, 0, sizeof(aSetup)); aSetup.modeFlags = DT2_TRIG_BUFF; aSetup.trigTgt = DT2_TGT_LED_0; aSetup.trigSrc = DT2_SRC_SI_00; aSetup.trigMode = DT2_TRIG_RISING; aSetup.index = 0; aSetup.modeType = DT2_MODE_PTT; aSetup.pulseDelay = 100000; aSetup.pulseWidth = 20000; // Configure parameters of the channel if (!DT2_Setup(&aSetup, sizeof(aSetup))) { printf("DT2 Setup fail \n"); return 0; } // Config LED0 as CC mode and set the current as 10 mA DWORD pins = (0x00010000) << 0; DWORD mode = (pins) LED_MODE_CC; if (LED_SetCurrentDriving(mode, 10) == false) { printf("Initial LED failed \n"); } </pre>

```
        return 0;
    }

    // Start Deterministic Trigger I/O v2 operation
    if (!DT2_Start())
    {
        printf("DT2_start failed \n");
        return 0;
    }

    //Change the status of SI0 from 0 -> 1 and set 1->0 to create pulse
    // We produce five times of pulse in this for loop
    for (int i = 0; i < 5; ++i)
    {
        if (!DT2_StPush(0xFFFFFFFF, 0))
        {
            printf("DT2_StPush failed \n");
            return 0;
        }

        Sleep(10);

        if (!DT2_StPush(0xFFFFFFFF, 1))
        {
            printf("DT2_StPush failed \n");
            return 0;
        }

        Sleep(1000);

        printf("Software trigger: %d \n", i);
    }

    Sleep(10000);

    // Stop Deterministic Trigger I/O v2 operation
    if (!DT2_Stop())
```

```
{  
    printf("DT2_Stop failed \n");  
    return 0;  
}  
  
return 0;  
}
```

Advanced DTIOv2 Example 2 - External Input

Description	This example demonstrates the feature of External Input. LED0 is triggered by SI0 and "External Input" function is used to control the behavior of LED0. If the index is odd, send activate pulse command. If the index is even, send deactivate pulse command.
--------------------	---

Usage	<pre>static void __stdcall __IndexedHandler(DWORD index) { /* If the index is odd number, send 1 back. The trigger target will change the status to pulse high. If the index is even number, send 0 back. The trigger target will stay as pulse low. */ printf("data %d \n", index); if (index % 2 == 1) { if (!DT2_EiSendResult(index, 1)) { printf("DT2_EiSendResult failed \n"); } } else { if (!DT2_EiSendResult(index, 0)) { printf("DT2_EiSendResult failed \n"); } } } int externalInputDT2() { //Reset configuration of each channel. initialChannel(); // Trigger DO0 by SI0 based on PTT mode</pre>
--------------	--

```
// Enable external input
// User can determine the trigger source status by the message
from computer
DT2_SETUP  aSetup;
memset(&aSetup, 0, sizeof(aSetup));
aSetup.modeFlags = DT2_TRIG_EIDD;
aSetup.trigTgt = DT2_TGT_LED_0;
aSetup.trigSrc = DT2_SRC_SI_00;
aSetup.trigMode = DT2_TRIG_RISING;
aSetup.index = 0;
aSetup.modeType = DT2_MODE_PTT;
aSetup.pulseDelay = 50000;
aSetup.pulseWidth = 20000;

if (!DT2_Setup(&aSetup, sizeof(aSetup)))
{
    printf("DT2 Setup fail \n");
    return 0;
}

// Config LED0 as CC mode and set the current as 10 mA
DWORD pins = 0x00010000;
DWORD mode = (pins) | LED_MODE_CC;
if (LED_SetCurrentDriving(mode, 10) == false)
{
    printf("Setting LED failed \n");
    return 0;
}

// Register callback function which can determine the status of the
trigger target
// Our mechanism will give each untriggered pulse a index
if (!DT2_EiRegisterIndexed(__IndexedHandler))
{
    printf("DT2_EiRegisterIndexed failed \n");
}
```

```
        return 0;

    }

    // Start Deterministic Trigger I/O v2 operation
    if (!DT2_Start())
    {
        printf("DT2_Start failed \n");
        return 0;
    }

    //Change the status of SI0 from 0 -> 1 and set 1->0 to create pulse
    // We produce five times of pulse in this for loop
    for (int i = 0; i < 5; ++i)
    {
        if (!DT2_StPush(0xFFFFFFFF, 0))
        {
            printf("DT2_StPush failed \n");
            return 0;
        }

        Sleep(10);

        if (!DT2_StPush(0xFFFFFFFF, 1))
        {
            printf("DT2_StPush failed \n");
            return 0;
        }

        Sleep(1000);

        printf("Software trigger: %d \n", i);
    }

    Sleep(3000);
```

```
    // Stop Deterministic Trigger I/O v2 operation
    if (!DT2_Stop())
    {
        printf("DT2_Stop failed \n");
        return 0;
    }

    return 0;
}
```

Pulse Width Modulator (PWM)

The Concept of Pulse Width Modulator (PWM)

Pulse Width Modulator can encode analog signal into digital signal by modulating the duty cycle of the square wave. It generates a high resolution square wave to control motor or switch power supply.

We provide Pulse Width Modulator (PWM) API for programming and operating the PWM controller. DTIOv2 contains two PWM generator blocks. Each generator block produces two PWM output signals. Two PWM output signals in the same generator block share the same timer and frequency.

Generator Block	PWM output signals
PWM_GEN_0	PWM_PIN_0
	PWM_PIN_1
PWM_GEN_1	PWM_PIN_2
	PWM_PIN_3

Configuring the Isolated Digital Output as PWM Output

Do4 ~ Do7 can be configured as PWM output (pin 0 ~ 3). We provide flexible methods to switch between Do output and PWM output.

If the pin bits are set by PWM_Start, those outputs are configured as PWM.

If the pin bits are stopped by PWM_Stop, those outputs are configured as Do.

PWM Function Reference

PWM_GenSetup

Syntax	<pre> BOOL __cdecl PWM_GenSetup(DWORD genBits, PWM_GEN_SETUP *lpSetup, DWORD cbSetup); </pre>										
Description	PWM clock settings configuration.										
Parameter	<p>genBits [in] Specifies the generator block bits of PWM controllers.</p> <p>lpSetup [in] A pointer to a PWM_GEN_SETUP structure that contains the PWM generator configuration. This data structure contains the following variables:</p> <p>genMode [in] Value specifies the generator mode of the specified PWM controller.</p> <table border="1"> <thead> <tr> <th>Mode</th><th>Value</th></tr> </thead> <tbody> <tr> <td>Down count Mode</td><td>PWM_GEN_MODE_DOWN (0x00000000)</td></tr> <tr> <td>Up/ down count Mode</td><td>PWM_GEN_MODE_UP_DOWN (0x00000002)</td></tr> <tr> <td>synchronous updates</td><td>PWM_GEN_MODE_SYNC (0x00000038)</td></tr> <tr> <td>Immediate updates</td><td>PWM_GEN_MODE_NO_SYNC (0x00000000)</td></tr> </tbody> </table> <p>intrTriggers [in] The variable is not available to users at this stage. Please set 0 to disable this variable.</p> <p>deadBandRise [in] The variable is not available to users at this stage. Please set 0 to disable this variable.</p> <p>deadBandFall [in] The variable is not available to users at this stage. Please set 0 to disable this variable.</p>	Mode	Value	Down count Mode	PWM_GEN_MODE_DOWN (0x00000000)	Up/ down count Mode	PWM_GEN_MODE_UP_DOWN (0x00000002)	synchronous updates	PWM_GEN_MODE_SYNC (0x00000038)	Immediate updates	PWM_GEN_MODE_NO_SYNC (0x00000000)
Mode	Value										
Down count Mode	PWM_GEN_MODE_DOWN (0x00000000)										
Up/ down count Mode	PWM_GEN_MODE_UP_DOWN (0x00000002)										
synchronous updates	PWM_GEN_MODE_SYNC (0x00000038)										
Immediate updates	PWM_GEN_MODE_NO_SYNC (0x00000000)										

	cbSetup [in] This variable is to set the length of the structure in bytes. The caller must set this member to size of (PWM_GEN_SETUP).
Return Value	Returns TRUE if procedure successful, FALSE if procedure failed.
Usage	PWM_GEN_SETUP setup; memset(&setup, 0, sizeof(setup)); setup.genMode = PWM_GEN_MODE_UP_DOWN PWM_GEN_MODE_NO_SYNC; BOOL returnValue = PWM_GenSetup(PWM_GEN_0, &setup, sizeof(setup));

PWM_GenPeriod

Syntax	BOOL __cdecl PWM_GenPeriod(DWORD genBits, DWORD period);
Description	Set the period of a PWM generator.
Parameter	genBits [in] Specifies the generator block bits of PWM controllers. period [in] Specifies the period of PWM generator output, measured in clock ticks.
Return Value	Returns TRUE if procedure successful, FALSE if procedure failed.
Usage	BOOL returnValue = PWM_GenPeriod(PWM_GEN_0 PWM_GEN_1, 800); // 100 KHz

PWM_PulseWidth

Syntax	BOOL __cdecl PWM_PulseWidth(DWORD pinBits, DWORD width);
Description	Set the pulse width for the specified PWM output.
Parameter	<p>pinBits [in] Specifies the output bits of PWM controllers.</p> <p>width [in] Specifies the width of the pulse.</p>
Return Value	Returns TRUE if procedure successful, FALSE if procedure failed.
Usage	BOOL returnValue = PWM_PulseWidth(PWM_PIN_0 PWM_PIN_3, 400);

PWM_PulseInvert

Syntax	BOOL __cdecl PWM_PulseInvert(DWORD pinBits);
Description	Sets inversion mode for PWM outputs.
Parameter	<p>pinBits [in] Specify the output bits of PWM to be inverted.</p>
Return Value	Returns TRUE if procedure successful, FALSE if procedure failed.
Usage	BOOL returnValue = PWM_PulseInvert(PWM_PIN_0);

PWM_Start

Syntax	BOOL __cdecl PWM_Start(DWORD pinBits);
Description	Start PWM controller operation.
Parameter	<p>pinBits [in] Specifies the output bits of PWM controllers.</p>
Return Value	Returns TRUE if procedure successful, FALSE if procedure failed.
Usage	BOOL returnValue = PWM_Start(PWM_PIN_0 PWM_PIN_1);

PWM_Stop

Syntax	BOOL __cdecl PWM_Stop(DWORD pinBits);
Description	Stop PWM controller operation.
Parameter	pinBits [in] Specify the output bits of PWM controllers.
Return Value	Returns TRUE if stop procedure successful, FALSE if stop procedure failed.
Usage	BOOL returnValue = PWM_Stop(PWM_PIN_0 PWM_PIN_1);

PWM Example

Description In this PWM example, we utilize PWM functions to provide motor control. To begin, we setup the environment and start up PWM. Next, we accelerate the speed of motor by PWM_GenPeriod and PWM_PulseWidth function. Lastly, we slow down the motor linearly and to an eventual full stop.

Usage

```
int PWMStart()
{
    //Configure PWM
    PWM_GEN_SETUP  setup;
    memset(&setup, 0, sizeof(setup));
    setup.genMode |= PWM_GEN_MODE_DOWN;
    setup.genMode |= PWM_GEN_MODE_NO_SYNC;
    if(!PWM_GenSetup(PWM_GEN_0, &setup, sizeof(setup)))
    {
        printf("PWM SETUP fail \n");
        return 0;
    }

    // set the speed of PWM
    if ( ! PWM_GenPeriod(PWM_GEN_0, 65535) ) // 100 KHz
    {
        printf("PWM GenPeriod fail \n");
        return 0;
    }

    //Start PWM
    if ( ! PWM_Start(PWM_PIN_0) )
    {
        printf("PWM start fail \n");
        return 0;
    }

    return 0;
}
```

```

int PWMTriangleMode()
{

    for(int i = 0; i < 1 ; ++i)
    {

        // Accelerate the motor by setting PWM
        for(int count=0;count<460; count++)
        {

            if ( ! PWM_GenPeriod(PWM_GEN_0,
AccProfile[count]) ) // 100 KHz
            {

                printf("PWM GenPeriod fail \n");
                return 0;

            }

            if ( !
PWM_PulseWidth(PWM_PIN_0,AccProfile[count]>>1 ) )
            {

                printf("PWM Pulsewidth fail \n");
                return 0;

            }
            Sleep(5);

        }

        Sleep(10000);

        // Slow down the motor by setting PWM
        for(int count=459;count>0; count--)
        {

            if ( ! PWM_GenPeriod(PWM_GEN_0,
AccProfile[count]) ) // 100 KHz
            {

                printf("PWM GenPeriod fail \n");
                return 0;

            }

        }

    }

}

```

```
        if ( !
PWM_PulseWidth(PWM_PIN_0,AccProfile[count]>>1 ) )
        {
            printf("PWM Pulsewidth fail \n");
            return 0;
        }
        Sleep(5);

    }

}

// Must stop PWM
if ( ! PWM_Stop(PWM_PIN_0) )
{
    printf("PWM stop fail \n");
    return 0;
}

return 0;
}

int PWMControl()
{

    PWMStart();
    for(int i = 0; i < 1 ; ++i)
        PWMTriangleMode();

    return 0;
}
```

Advanced Examples

Combination PWM and DTIOv2

Description	In this example, we will introduce how to leverage DTIOv2 and PWM control simultaneously.
Usage	<pre> int PositionTriggerWithPWM() { // Start PWM //Must PWM start before QEI initial PWMStart(); //Reset configuration of each channel. initialChannel(); /*Fill the structure of DT2_SETUP 1. Define ppp mode to trigger LED by QEI source 2. Define ppp mode to trigger Camera by QEI source */ // Trigger LED when the position is 1000 and the LED will turn on from position 1000 to position 3000. DT2_SETUP aSetup; memset(&aSetup,0,sizeof(aSetup)); aSetup.trigTgt = DT2_TGT_LED_0; aSetup.trigSrc = DT2_SRC_QEI_0 ; aSetup.trigMode = DT2_TRIG_RISING; aSetup.index = 0 ; aSetup.modeType = DT2_MODE_PPP; aSetup.trigData = 1000; aSetup.pulseDelay =0; aSetup.pulseWidth =2000; //Trigger camera when the position is 1500. </pre>

```
DT2_SETUP  aSetup2;
memset(&aSetup2,0,sizeof(aSetup2));
aSetup2.trigTgt = DT2_TGT_TRIG_00;
aSetup2.trigSrc = DT2_SRC_QEI_0 ;
aSetup2.trigMode = DT2_TRIG_RISING;
aSetup2.index = 1 ;
aSetup2.modeType = DT2_MODE_PPP;
aSetup2.trigData = 1500;
aSetup2.pulseDelay =0;
aSetup2.pulseWidth =500;


// Configure parameters of the channel
if ( ! DT2_Setup(&aSetup, sizeof(aSetup)) )
{
    printf("DT2 Setup fail \n");
    return 0;
}


if ( ! DT2_Setup(&aSetup2, sizeof(aSetup2)) )
{
    printf("DT2 Setup fail \n");
    return 0;
}


//Set configuration of LED0
DWORD pins = (0x00010000) << 0;
//Set LED Mode as constant current
DWORD mode = (pins) | LED_MODE_CC;


// Set constant current as 100 mA. It means that LED is turned on.
if (LED_SetCurrentDriving(mode, 100) == false)
{
    printf("Setting LED failed \n");
    return 0;
}
```

```
// Initial  QEI configuration
QEIEncoderInit();

// Start Deterministic Trigger I/O v2 operation
if(!DT2_Start())
{
    printf("Starting DT2 failed \n");
    return 0;
}

// Start the PWM slowly and then acceralate to the highest velocity
we set. Keep the speed for      a while, and then slow down.
PWMTriangleMode();

// Stop DTIOv2
// Must stop before next start. If not, it will cause some errors.
if ( ! DT2_Stop() )
{
    printf("Stopping DT2 failed \n");
    return 0;
}
}
```